Innovens



MCA 25/28 BIC





Installation and Service Manual



300022159-001-01

EG declaration of conformity

The device complies with the standard type described in the EG declaration of conformity. It was manufactured and commissioned in accordance with European directives.

The original of the declaration of compliance is available from the manufacturer.

	RING VAN OVI ATION OF CON	REENSTEMMING	
	MITÄTSERKLA		
	N DE CONFOR		
DECLARATIO	IN DE CONFOR	MITE CE	
Fabrikant/Manufac	turer/Hersteller/Fab	icant : Remeha B.V.	
Adres/Address/Adr		: Kanaal Zuid 110	
Stad,Land/City,Cou	intry/Land,Ort/Ville,	pays : Postbus 32, NL-7300 AA	Apeldoorn
verklaart hiermede	dat de toestel(len)	: MCA/ (MI) (BIC)	
	t the following produ	ct(s) :	
erklärt hiermit das déclare ici que les p		:	
ucciare ici que ies p	rount(s) survant(s)	·	
op de markt gebrac		ch Thermique	
distributor Vertreiber	: 57, rue d	e la Gare, F-67580	
Commercialisé (s) p			
	1.1		
	with the following E	e onderstaande EEG-richtlijnen: EC-directives:	
den Bestimmungen	der nachfolgenden E	G-Richtlinien entspricht/entsprechen:	
répond/répondent a	ux directives CEE su	ivantes:	
EEG-Richtlijn:	2009/142/EC	toegepaste normen:	
EEC-Directive:	2009/142/EC	tested and examined tothe following	
EG-Richtlinie: CEE-Directive:	2009/142/EG 2009/142/CE	verwendete Normen, normes appliq EN 297(1994*), 483(1999*), 677(1998*)	uées:
CEE-Directive:	2009/142/CE	EIN 297(1994^), 483(1999^), 077(1998^)	
	92/42/EEG		
	92/42/EEC 92/42/EWG		
	92/42/CEE		
	2006/95/EEG	EN 50165(1997*), EN 60335-1(1994*)	CE
	2006/95/EEC	EN 60335-2-102(2004*)	08
	2006/95/EWG		
	2006/95/CEE		
	2004/108/EEG	EN 50165(1997*)	
	2004/108/EEC 2004/108/EWG	EN 55014-2(1997*), EN 55014-1(2000*), EN 61000 3 2(2000*), 61000 3 2(2005*)	
	2004/108/EWG 2004/108/CEE	EN 61000-3-2(2000*), 61000-3-3(1995*)	
	97/23/EEG 97/23/EEC	(art. 3, lid 3) (article 3, sub 3)	
	97/23/EWG	(Art. 3, Abzats 3)	
	97/23/CEE	(art.3 section 3)	
	*) inclusief (eventuele) aan	vulling, including (if any) completion	
	einschließlich (falls vor	nanden) Vervollständigung, y compris (le cas échéant) con	nplément
aldoorn fahmam 2010			
beldoorn, february 2010			
NOV IL			
w to			
.F. Tijhuis			
proval manager //2012/02/232			

Contents

1	Introduction			6
		1.1	Symbols used	6
		1.2	Abbreviations	6
		1.3	General	7
			1.3.1Manufacturer's liability1.3.2Installer's liability	
		1.4	Homologations	7
			1.4.1 Certifications	
			1.4.2 Equipment categories1.4.3 Additional Directives	
			1.4.4Factory test	
2	Safety instructions an	d rec	ommendations	9
		2.1	Safety instructions	9
		2.2	Recommendations	9
3	Technical description			11
		3.1	General description	11
		3.2	Main parts	11
		3.3	Operating principle	12
			3.3.1 Skeleton Diagrams	
			3.3.2 Shunt pump 3.3.3 Water flow rate	
		3.4	Technical specifications	13
			3.4.1 Sensor characteristics	14
4	Installation			15
		4.1	Regulations governing installation	15
		4.2	Package list	15
			4.2.1 Standard delivery4.2.2 Accessories	
		4.3	Choice of the location	16
			4.3.1 Data plate	
			4.3.2 Location of the boiler4.3.3 Ventilation	
			4.3.3 Ventilation4.3.4 Main dimensions	
				-

De Dietrich 📀

4.4	Installir	ng the mounting frame	19
4.5	Positio	ning the boiler	19
4.6	Hydrau	lic connections	20
	4.6.1 4.6.2 4.6.3	Flushing the system Connection of the heating circuit Connection of the water circuit for domestic use	21
	4.6.4 4.6.5	Connecting the expansion vessel Connecting the condensate discharge pipe	22
4.7	Gas co	nnection	23
4.8	Flue ga	s system connections	24
	4.8.1 4.8.2 4.8.3	Classification Lengths of the air/flue gas pipes Additional Directives	25
4.9	Installir	ng the outside sensor	27
	4.9.1 4.9.2	Choice of the location Connecting the outside sensor	
4.10	Electric	al connections	28
	4.10.1 4.10.2 4.10.3 4.10.4 4.10.5 4.10.6 4.10.7	Control unit Recommendations Position of the PCBs Accessing the connection terminal blocks Connecting a direct heating circuit Connecting two heating circuits Hot water storage tank connection (Type	29 30 31 33
	4.10.8 4.10.9	PS) Pool connection Connecting the options	37
4.11	Electric	al diagram	40
4.12	Filling t	he system	41
	4.12.1 4.12.2 4.12.3	Water treatment Filling the siphon Filling the system	42
Commissioning			44
5.1	Control	panel	44
	5.1.1 5.1.2 5.1.3 5.1.4	Description of the keys Description of the display Access to the various browsing levels Browsing in the menus	45 48
5.2	Check	points before commissioning	50
	5.2.1 5.2.2 5.2.3 5.2.4	Preparing the boiler for commissioning Gas circuit Hydraulic circuit Electrical connections	51 51

5

De Dietrich 📀

5	5.3	Comm	issioning the boiler	51
5	5.4	Gas se	ettings	52
		5.4.1	Adapting to another gas type	
		5.4.2	Setting the air/gas ratio (Full load)	
		5.4.3	Setting the air/gas ratio (Part load)	
		5.4.4	Basic setting for the gas/air ratio	
5	5.5	Check	s and adjustments after	
			issioning	56
		5.5.1	Displaying the parameters in extended	
			mode	56
		5.5.2	Setting the parameters specific to the	
			installation	
		5.5.3	Naming the circuits and generators	
		5.5.4 5.5.5	Setting the heating curve Finalizing work	
		5.5.5		04
5	5.6	Readir	ng out measured values	65
F	5.7	Chang	ing the settings	66
		5.7.1		
		5.7.1 5.7.2	Language selection	
		5.7.2 5.7.3	Calibrating the sensors Professional settings	
		5.7.3 5.7.4	Configuring the network	
		5.7.5	Return to the factory settings	
		0.7.0		
Switching off the boiler .	•••••			80
e	6.1	Install	ation shutdown	80
e	6.2	Frost j	protection	80
Checking and maintenar	ice .			81
-	7.1		al instructions	
	7.2		ey sweep instructions	
	7.3		mising maintenance	
, i i i i i i i i i i i i i i i i i i i	.5		-	
		7.3.1 7.3.2	Maintenance message	
		1 5 /	Contact details of the professional for After S	sales
		1.0.2	•	0.0
		1.0.2	Support	83
7	7.4	Standa	Support	
7	7.4	Standa operat	Support ard inspection and maintenance tions	83
7	7.4	Standa operat	Support ard inspection and maintenance tions Checking the hydraulic pressure	83 84
7	7.4	Standa operat 7.4.1 7.4.2	Support ard inspection and maintenance tions Checking the hydraulic pressure Checking the expansion vessel	83 84 84
7	7.4	Standa operat 7.4.1 7.4.2 7.4.3	Support ard inspection and maintenance tions Checking the hydraulic pressure Checking the expansion vessel Checking the ionization current	83 84 84 84
7	7.4	Standa operat 7.4.1 7.4.2 7.4.3 7.4.4	Support ard inspection and maintenance tions Checking the hydraulic pressure Checking the expansion vessel Checking the ionization current Checking the transfer capacity	83 84 84 84 84
7	7.4	Standa operat 7.4.1 7.4.2 7.4.3	Support ard inspection and maintenance tions Checking the hydraulic pressure Checking the expansion vessel Checking the ionization current Checking the transfer capacity Checking the tightness of the flue gas evacua	83 84 84 84 84 ation and
7	7.4	Standa operat 7.4.1 7.4.2 7.4.3 7.4.3 7.4.4 7.4.5	Support ard inspection and maintenance tions Checking the hydraulic pressure Checking the expansion vessel Checking the ionization current Checking the transfer capacity Checking the tightness of the flue gas evacua air inlet connections	83 84 84 84 ation and 84
7	7.4	Standa operat 7.4.1 7.4.2 7.4.3 7.4.3 7.4.4 7.4.5 7.4.6	Support ard inspection and maintenance tions Checking the hydraulic pressure Checking the expansion vessel Checking the ionization current Checking the transfer capacity Checking the tightness of the flue gas evacua air inlet connections Checking combustion	83 84 84 84 ation and 84 85
7	7.4	Standa operat 7.4.1 7.4.2 7.4.3 7.4.3 7.4.4 7.4.5 7.4.6 7.4.6 7.4.7	Support ard inspection and maintenance tions Checking the hydraulic pressure Checking the expansion vessel Checking the ionization current Checking the transfer capacity Checking the tightness of the flue gas evacua air inlet connections Checking combustion Checking the automatic air vent	83 84 84 84 ation and 84 85 86
7	7.4	Standa operat 7.4.1 7.4.2 7.4.3 7.4.3 7.4.4 7.4.5 7.4.6	Support ard inspection and maintenance tions Checking the hydraulic pressure Checking the expansion vessel Checking the ionization current Checking the transfer capacity Checking the tightness of the flue gas evacua air inlet connections Checking combustion	83 84 84 84 ation and 85 86 86

6

7



			7.4.10	Checking the burner and cleaning the heat exchanger	87
		7.5	Specif	fic maintenance operations	88
			7.5.1 7.5.2 7.5.3 7.5.4 7.5.5 7.5.6	Replacing the ionization/ignition electrode Cleaning the plate exchanger Replacing the boiler tanks Replacing the 3-way valve Replacing the non-return valve Assembling the boiler	89 90 91 92
8	Troubleshooting				94
		8.1	Anti-h	unting	94
		8.2	Messa	ages (Code type Bxx or Mxx)	94
		8.3	Messa	age history	97
		8.4	Faults	(Code type Lxx or Dxx)	97
			8.4.1	Deletion of sensors from the memory in the PCB	106
		8.5	Failur	e history	106
		8.6		neter and input/output check (mode	107
			8.6.1	Control system sequence	
9	Spare parts				111
		9.1	Gener	al	111
		9.2	Spare	parts	111
			9.2.1 9.2.2 9.2.3 9.2.4 9.2.5 9.2.6	Casing Heat exchanger and burner Fan Control panel Connecting pipes Spare parts list	113 114 115 116








1 Introduction

1.1 Symbols used

In these instructions, various danger levels are employed to draw the user's attention to particular information. In so doing, we wish to safeguard the user's safety, obviate hazards and guarantee correct operation of the appliance.





CAUTION

Risk of material damage.



Signals important information.

Signals a referral to other instructions or other pages in the instructions.

1.2 Abbreviations

- 3CE: Collective conduit for sealed boiler
- DHW: Domestic hot water
- Hi: Lower heating value LHV (Nett)
- Hs: Higher heating value HHV (Gross)
- > PPS: Polypropylene hardly inflammable
- > PCU: Primary Control Unit PCB for managing burner operation
- PSU: Parameter Storage Unit Parameter storage for PCBs PCU and SU
- SCU: Secondary Control Unit control panel PCB
- SU: Safety Unit Safety PCB
- ► **3WV**: 3-way valve

1.3.1. Manufacturer's liability

Our products are manufactured in compliance with the requirements of the various applicable European Directives. They are therefore

delivered with **((** marking and all relevant documentation.

In the interest of customers, we are continuously endeavouring to make improvements in product quality. All the specifications stated in this document are therefore subject to change without notice.

Our liability as the manufacturer may not be invoked in the following cases:

- Failure to abide by the instructions on using the appliance.
- Faulty or insufficient maintenance of the appliance.
- Failure to abide by the instructions on installing the appliance.

1.3.2. Installer's liability

The installer is responsible for the installation and initial start up of the appliance. The installer must respect the following instructions:

- Read and follow the instructions given in the manuals provided with the appliance.
- Carry out installation in compliance with the prevailing legislation and standards.
- Perform the initial start up and carry out any checks necessary.
- Explain the installation to the user.
- If a maintenance is necessary, warn the user of the obligation to check the appliance and maintain it in good working order.
- Give all the instruction manuals to the user.

1.4 Homologations

1.4.1. Certifications

CE identification no	PIN 0063BT3444
NOx classification	5 (EN 297 pr A3, EN 656)
Type of connection	Chimney: B ₂₃ ⁽¹⁾ , B ₂₃ P ⁽¹⁾ , B ₃₃
	Flue gas outlet: $C_{13(x)}$, $C_{33(x)}$, $C_{43(x)}$, C_{53} , $C_{63(x)}$, $C_{83(x)}$, $C_{93(x)}$
(1) IP20	



1.4.2. Equipment categories

Gas category	Gas type	Connection pressure (mbar)
II _{2ESi3P}	Natural gas H (G20)	20
	Natural gas L (G25)	25
	Propane (G31)	37

The boiler is preset in the factory to operate on natural gas H (G20).

For operation on another type of gas, see chapter: "Adapting to another gas type", page 52.

1.4.3. Additional Directives

Apart from the legal provisions and Directives, the additional Directives described in these instructions must also be observed.

For all provisions and Directives referred to in these instructions, it is agreed that all addenda or subsequent provisions will apply at the time of installation.



WARNING

Installation of the appliance must be done by a qualified engineer in accordance with prevailing local and national regulations.

1.4.4. Factory test

Before leaving the factory, each boiler is set for optimum performance and tested to check the following items:

- Electrical safety
- Adjustment (CO₂)
- Water tightness
- Gas tightness
- Parameter settings

2 Safety instructions and recommendations

2.1 Safety instructions



DANGER

If you smell gas:

- 1. Do not use a naked flame, do not smoke, do not operate electrical contacts or switches (doorbell, light, motor, lift, etc..).
- 2. Shut off the gas supply.
- 3. Open the windows.
- 4. Trace possible leaks and seal them immediately.
- 5. If the gas leak is before the gas meter, contact the gas supplier.



DANGER

If you smell flue gases:

- 1. Switch the appliance off.
- 2. Open the windows.
- 3. Trace possible leaks and seal them immediately.

2.2 Recommendations



WARNING

- Installation and maintenance of the boiler must be carried out by a qualified professional in compliance with prevailing local and national regulations.
- When working on the boiler, always disconnect the boiler from the mains and close the main gas inlet valve.
- After maintenance or repair work, check all installations to ensure that there are no leaks.



CAUTION

The boiler must be installed in a frost-free environment.



Keep this document close to the place where the boiler is installed.

Casing components

Only remove the casing for maintenance and repair operations. Put the casing back in place after maintenance and repair operations.

Instructions stickers

The instructions and warnings affixed to the appliance must never be removed or covered and must remain legible during the entire lifespan of the appliance. Immediately replace damaged or illegible instructions and warning stickers.

Modifications

Modifications may only be made to the boiler after the written permission of **De Dietrich Thermique** to do so.


3 Technical description

3.1 General description

Wall-hung gas condensing boilers

- High efficiency heating.
- Low pollutant emissions.
- Top of the range electronic **DIEMATIC iSystem** control panel.
- Installation and connection facilitated by the mounting frame delivered with the appliance.
- Flue gas discharge via a forced flue, chimney, bi-flow or 3CE type connection.
- Heating and domestic hot water production with integrated DHW tank.


3.2 Main parts



- Flue gas discharge pipe
- Casing/air box
- Flue gas measuring point
- Mixer pipe
- Heating flow hose
- Air intake silencer
- Box for the control PCBs
- Combined venturi and gas valve unit
- Flow end hydroblock
- Safety valve outlet pipe
- Siphon
- Control panel
- Tank drainage valve
- Expansion vessel (DHW circuit)
- Tank hydroblock
- Shunt pump (DHW circuit)
- Shunt pump (Heating circuit)
- Return end hydroblock
- **19** Plate heat exchanger (DHW circuit)
- **20** 3-way valve
- 21 Condensate receiver tank
- **22** Fan

- 23 Heat exchanger (Heating circuit)
- 24 Calorifier tank
- 25 Ignition/ionization electrode
- 26 Expansion vessel (Heating circuit)
- 27 Air intake

3.3 Operating principle



3.3.1. Skeleton Diagrams

Hydroblocks Plate heat exchanger (DHW circuit) Heating flow Domestic hot water outlet Domestic cold water inlet Heating return Shunt pump (DHW circuit) Expansion vessel (DHW circuit) 3-way valve Shunt pump (Heating circuit) Calorifier tank Expansion vessel (Heating circuit)


Heat exchanger (Heating circuit)

3.3.2. Shunt pump

The boiler is equipped with a circulating pump. This energy-efficient, modulating circulating pump is controlled by the control unit based on ΔT . The graph shows the manometric height at various outputs.

- H Manometric height central heating circuit
- Q Water flow

The parameters **MIN.PUMP SPEED** and **MAX.PUMP SPEED** are used to modify the pump settings. If flow noise can be heard in the system, it is possible to reduce the maximum pump speed with the parameter **MAX.PUMP SPEED** (First of all, vent the heating system). If circulation in the radiators is too low or the radiators do not fully heat up, increase the minimum pump speed with the parameter **MIN.PUMP SPEED**.



See chapter: "Professional settings", page 68.

3.3.3. Water flow rate

The boiler's modulating control system limits the maximum difference in temperature between the heating flow and return and the maximum speed at which the flow temperature increases. In this way, the boiler does not require a minimum water flow rate.

3.4 Technical specifications

Boiler type			MCA 25/28 BIC		
General					
Flow rate setting	Adjustable		Modulating, Start/Stop, 0 - 10 V		
Nominal output (Pn)	minimum-maximum	kW	5,0 - 24,1		
Heating System (80/60 °C)	Factory setting	kW	19,4		
Nominal output (Pn)	minimum-maximum	kW	5,6 - 25,5		
Heating System (50/30 °C)	Factory setting	kW	20,5		
Nominal output (Pn)	minimum-maximum	kW	5,0 - 29,9		
DHW System	Factory setting	kW	29,9		
Nominal input (Qn)	minimum-maximum	kW	5,2 - 25,0		
Heating System (Hi)	Factory setting	kW	20,1		
Nominal input(Qn)	minimum-maximum	kW	5,8 - 27,8		
Heating System (Hs)	Factory setting	kW	22,3		
Nominal input (Qnw)	minimum-maximum	kW	5,2 - 29,3		
DHW System (Hi)	Factory setting	kW	29,3		
Nominal input (Qnw)	minimum-maximum	kW	5,8 - 32,6		
DHW System (Hs)	Factory setting	kW	32,6		
Heating efficiency under full load (Hi) (80/60 °C)	-	%	96,3		
Heating efficiency under full load (Hi) (50/30 °C)	-	%	102,0		
Heating efficiency under partial load (Hi) (Return temperature 60°C)	-	%	96,1		
Heating efficiency under partial load (EN 92/42) (Return temperature 30°C)	-	%	108,0		
Data on the gases and combustion gases	•		•		
Gas consumption - Natural gas H (G20)	minimum-maximum	m ³ /h	0,55 - 3,10		
Gas consumption - Natural gas L (G25)	minimum-maximum	m ³ /h	0,64 - 3,61		
Gas consumption - Propane G31	minimum-maximum	m ³ /h	0,21 - 1,20		
NOx-Emission per year (n =1)		mg/kWh	38		
Mass flue gas flow rate	minimum-maximum	kg/h	8,9 - 49,3		
Flue gas temperature	minimum-maximum	°C	30 - 85		
Maximum counter pressure		Ра	130		
Characteristics of the heating circuit	•	•			
Water content		1	1,8		
Water operating pressure	minimum	kPa (bar)	80 (0,8)		
Water operating pressure (PMS)	maximum	kPa (bar)	300 (3,0)		
Water temperature	maximum	°C	110		
Operating temperature	maximum	°C	90		
(1) Front panel removed					



Boiler type			MCA 25/28 BIC
Manometric height central heating circuit ($\Delta T = 20K$)		mbar	295
Characteristics of the domestic hot water circuit			•
Specific hot water flow D (60 °C)		l/min	7,5
Specific hot water flow D (30 °C)		l/min	20,0
Domestic water resistance		mbar	20
Water content		1	40,5
Operating pressure (Pmw)	maximum	kPa (bar)	800 (8,0)
Electrical characteristics		2	•
Power supply voltage		VAC	230
Power concumption Full load	maximum	W	162
Power consumption - Full load	Factory setting	W	72
Power consumption - Part load	maximum	W	21
Power consumption - Standby	maximum	W	4
Electrical protection index			IPX4D
Other characteristics		3	•
Mainte (amonto)	Total	kg	70
Weight (empty)	Mounting ⁽¹⁾	kg	61
Acoustic level at 1 metre		dB(A)	44
(1) Front panel removed		-	•

3.4.1. Sensor characteristics

Outside sensor												
Temperature in °C	-20	-16	-12	-8	-4	0	4	8	12	16	20	24
Resistance in Ω	2392	2088	1811	1562	1342	1149	984	842	720	616	528	454

Outlet sensor circuit B+C Domestic hot water sensor System sensor Flow sensor - Return sensor NTC											
Temperature in °C	0	10	20	25	30	40	50	60	70	80	90
Resistance in Ω	32014	19691	12474	10000	8080	5372	3661	2535	1794	1290	941

4 Installation

4.1 Regulations governing installation



WARNING

Installation of the appliance must be done by a qualified engineer in accordance with prevailing local and national regulations.

4.2 Package list

4.2.1. Standard delivery

The delivery includes:

- > The boiler, fitted with a connection cable
- Mounting frame
- Mounting template
- Connection kit
- Run-off collector for siphon and safety valve
- Outside sensor
- Installation and Service Manual
- User Guide

4.2.2. Accessories


Various options are available depending on the configuration of the installation:

Boiler options		Control system options				
Description	package	Description	package			
Stand-off frame	HR39	RX12 cable	AD134			
Pipework kit for stand-off frame	HR40	TELCOM 2 voice remote monitoring module	AD152			
Pipe cover	HR42	Flow sensor	AD199			
Flue gas thermostat	HR43	DHW sensor	AD212			
adapter 80/125	HR38	Optional PCB for 3-way valve	AD249			
adapter 80-80	HR46	Hot water storage tank sensor	AD250			
Exchanger cleaning kit	HR44	Outside radio-controlled temperature sensor	AD251			
Boiler body cleaning kit	HR45	Boiler radio module	AD252			
		Radio remote control	AD253			
		Interactive remote control	AD254			
		Room sensor	FM52			



4.3 Choice of the location

4.3.1. Data plate



The data plate located on top of the boiler provides important information on the appliance: serial number, model, gas category, etc.

4.3.2. Location of the boiler

- Before mounting the boiler, decide on the ideal position for mounting, bearing the Directives and the dimensions of the appliance in mind.
- When choosing the position for mounting the boiler, bear in mind the authorised position of the combustion gas discharge outlets and the air intake opening.
- To ensure adequate accessibility to the appliance and facilitate maintenance, leave enough space around the boiler.




WARNING

- Fix the appliance to a solid wall capable of bearing the weight of the appliance when full of water and fully equipped.
- It is forbidden to store inflammable products and materials in the boiler room or close to the boiler, even temporarily.



CAUTION

- The boiler must be installed in a frost-free environment.
- A connection to the mains drainage system for the discharge of condensate must be available close to the boiler.




4.3.3. Ventilation

- (1) Distance between the front of the boiler and the internal wall of the casing box.
- (2) Distance to allow on either side of the boiler.

If the boiler is installed in a closed casing, respect the minimum dimensions given in the diagram opposite. Also allow openings to obviate the following hazards:


- Accumulation of gas
- Heating of the box


Minimum cross section of the openings: S1 + S2 = 150 cm^2





4.3.4. Main dimensions





Connection of the combustion gas exhaust pipe Ø 60 mm

- Connection of the air intake pipe Ø 100 mm
- Safety valve outlet pipe Ø 25 mm
- Condensates discharge Ø 25 mm
- Heating circuit return G¾"
- Domestic cold water inlet G¹/₂"
- Gas / Gas connection G¹/₂"
 - Domestic hot water outlet G¹/₂"
 - Heating circuit flow G¾"

 $(\mathbf{\overline{n}})$

R


(FJ)

Gaz

 $(\underline{})$

 $(\mathbf{P}_{\mathbf{III}})$

4.4 Installing the mounting frame



The boiler is delivered with a mounting template.

1. Position the mounting template to the wall with adhesive tape.



CAUTION

Using a spirit level, check that the mounting axis is perfectly horizontal.


2. Drill 3 holes with a Ø of 10 mm.



Additional holes are provided in case one or other of the standard locating holes prevents the correct location of the plugs.

- 3. Put the plugs in place.
- 4. Secure the mounting frame to the wall using the 3 hexagonal headed screws provided for this purpose.

4.5 Positioning the boiler



1. Remove the protective caps from all of the hydraulic inlets and outlets on the boiler.



- 2. Fit a fibre gasket to each joint on the valve plate.

- 3. Position the boiler above the plumbing fixtures plate and locate it against the mounting frame. Gently lower the boiler.
- 4. Tighten the valve nuts on the boiler.

4.6 Hydraulic connections

T001872-A

4.6.1. Flushing the system

Installation must be carried out in accordance with the prevailing regulations, the codes of practice and the recommendations in these instructions.

Installing the boiler in new installations (installations less than 6 months old)


- Clean the installation with a universal cleaner to eliminate debris from the appliance (copper, hemp, flux).
- Thoroughly flush the installation until the water runs clear and shows no impurities.

Installing the boiler in existing installations


• Remove sludge from the installation.

- Flush the installation.
- Clean the installation with a universal cleaner to eliminate debris from the appliance (copper, hemp, flux).
- Thoroughly flush the installation until the water runs clear and shows no impurities.

4.6.2. Connection of the heating circuit



- 1. Connect the cold water inlet pipe to the domestic cold water connection.
- 2. Connect the domestic hot water outlet pipe to the domestic hot water connection.



- Connection by internal brazing \varnothing 16 mm
- Connection by internal brazing \varnothing 16 mm

CAUTION

(F4)

Ę)

- The domestic water pipes must be connected in accordance with prevailing provisions.
- If using synthetic pipes, follow the manufacturer's (connection) instructions.

4.6.4. Connecting the expansion vessel

The boiler is fitted as standard with an 12-litre expansion vessel.

If the water volume is greater than 150 litres or the static height of the system exceeds 5 metres, an additional expansion vessel must be fitted. Refer to the table below to determine the expansion vessel required for the installation.

Conditions of validity of the table:


- ▶ 3-bar safety valve
- Average water temperature: 70 °C Supply temperature: 80 °C Return temperature: 60 °C
- The filling pressure in the system is lower than or equal to the initial pressure in the expansion vessel

Initial pressure of the	Volun	Volume of the expansion vessel depending on the volume of the installation (in litres)						
expansion vessel	100	125	150	175	200	250	300	> 300
0.5 bar	4,8	6,0	7,2	8,4	9,6	12,0	14,4	Volume of the installation x 0,048
1 bar	8,0	10,0	12,0 ⁽¹⁾	14,0	16,0	20,0	24,0	Volume of the installation x 0,080
1.5 bar	13,3	16,6	20,0	23,3	26,6	33,3	39,9	Volume of the installation x 0,133
(1) Factory configuration								



It is possible to fit the boiler with an expansion vessel for DHW (package option HG77) under the integrated expansion vessel for heating.





4.6.5. Connecting the condensate discharge pipe


- 1. Mount a standard drainage pipe, \emptyset 32 mm or more, leading to the mains drainage system.
- 2. Mount the flow collector.
- 3. Into this, insert the condensate collector hose coming from the siphon and the safety valve ().
- 4. Into this, insert the discharge hose from the disconnector.
- 5. Mount a trap or a siphon in the discharge pipe.

CAUTION

Do not make a fixed connection owing to maintenance work on the siphon.

- Do not plug the condensate discharge pipe.
- Set the discharge pipe at a gradient of at least 30 mm per metre, maximum horizontal length 5 metres.
- Do not drain condensation water into a roof gutter at any time.
- Connect the condensate discharge pipe in accordance with prevailing standards.

4.7 Gas connection



Ð

The diameters of the pipes must be defined in accordance with the standards in force in your country.

Connection by internal brazing \varnothing 18 mm

1. Connect the gas inlet pipe.

CAUTION


$\underline{\wedge}$

- WARNING
 Close the main gas valve before starting work on the gas pipes.
- Before mounting, check that the gas meter has sufficient capacity. To do this, you should keep in mind the consumption of all domestic appliances.
- If the gas meter has too low a capacity, inform the energy supply company.

\triangle

- Ensure that there is no dust in the gas pipe. Blow into the pipe or shake it before mounting.
- We recommend installing a gas filter on the gas pipe to prevent clogging of the gas valve unit.
- Connect the gas pipe in accordance with prevailing standards and regulations.

4.8 Flue gas system connections



2

3

4

5

6

7

Classification 4.8.1.

Configuration B₃₃

Connection to a collective pipe via a concentric pipe (combustive air taken from the boiler room) All of the pressurised parts of the appliance are surrounded by air.

Configuration B₂₃ - B_{23P}

Connection to a chimney using a connection kit (combustive air taken from the boiler room)

Configuration C_{13(x)}

Air/flue gas connection by means of concentric pipes to a horizontal terminal (so-called forced flue)

Configuration C_{33(x)}

Air/flue gas connection by means of concentric pipes to a vertical terminal (roof outlet)

Configuration C_{43(x)}

Air/flue gas connection to a collective conduit for watertight boilers (3CE P system)

Configuration C₅₃

Air and flue gas connection separated by means of a biflow adapter and single pipes (combustive air taken from outside)

Configuration C_{83(x)}

Flue gas connection to a collective conduit for sealed boilers. The air supply is individual via a terminal coming from outside the building.

Configuration C_{93(x)}

8

9

Air/flue gas connection by concentric pipes in the boiler room and single pipes in the chimney (combustive air in counter current in the chimney)

Configuration C_{93(x)}

Air/flue gas connection by concentric pipes in the boiler room and single flex in the chimney (combustive air in counter current in the chimney)



- Only factory components are authorised for connecting the boiler and the terminal.
- The clear section must comply with the standard.
- The chimney must be swept before the installation of the evacuation conduit.

4.8.2. Lengths of the air/flue gas pipes

i

For configurations B23 and C93, the lengths given in the table are valid for horizontal conduits with a maximum length of 1 metre. For each additional metre of horizontal conduit, subtract 1.2 m from the vertical length Lmax

Туре о	of air/flue gas connection		Diameter	Maximum length in metres		
				MCA 25/28 BIC		
B ₃₃	Collective conduit To determine the dimensions of such a system, refer to the supplier collective conduit.					
B ₂₃	Chimney (rigid or flexible duct in	PPS	80 mm (Rigid duct)	40.0		
В _{23Р}	chimney, combustive air taken from the premises)		80 mm (Flexible duct)	40.0		
	Concentric pipes connected to a	Alu or PPS	60/100 mm	4.2		
	horizontal terminal		80/125 mm	20.0		
00(,1)	Concentric pipes connected to a vertical	Alu or PPS	60/100 mm	5.5		
	terminal		80/125 mm	20.0		
C _{43(x)}	Collective conduit for sealed boiler (3 CEP)	To determine the size of such a system, consult the supplier of the 3 CEP conduit.				
C ₅₃	Bi-flow adapter and separate single air/	Alu	60/100 mm	40.0		
	flue gas ducts (combustive air taken from outside)		2 x 80 mm			
C _{83(x)}	Collective conduit for sealed boiler	To determine the dimensions of such a system, refer to the supplier of the collective conduit.				
C _{93(x)}	Concentric pipes in the boiler room	Alu or PPS	60/100 mm	9.0		
	Single conduits in the chimney (combustive air in counter-current)		60 mm (Rigid duct)			
	Concentric pipes in the boiler room	PPS	60/100 mm	20.0		
	Flexible single conduit in the chimney		80 mm (Flexible duct)			



WARNING

Maximum length = lengths of the straight air/flue gas ducts + equivalent lengths of other components

The max length in the flue gas pipe (configurations C_{93} , B_{23P}) of the elbow bracket at the outlet must not exceed:

- ▶ 30 m for rigid PPS
- > 25 m for flexible PPS

If longer lengths are used, holding clamps must be added per sections of 25 or 30 metres.

For the list of flue gas system accessories and the equivalent lengths, refer to the current price list.

4.8.3. Additional Directives

- Please refer to the manufacturer's instructions for the material in question when installing the flue gas discharge and air supply materials. If the flue gas discharge and air supply materials are not installed according to the instructions (e.g. they are not leakproof, not clamped in place etc.), this may cause hazardous situations and/or result in bodily injury. After assembly, check at least all flue gas and air-carrying parts for tightness.
- Connection of the combustion gas exhaust directly to the buildings brick chimneys or flues is forbidden for condensation reasons.
- Always clean the ducts thoroughly in cases where lining pipes are used and/or a connection of the air-supply.
- It must be possible to inspect the flue or chimney.
- For long, aluminium, combustion-gas exhaust pipes it is initially necessary to consider the relatively high quantity of corrosive products which are brought together with the condensate from the exhaust pipe. The siphon on the equipment requires regular cleaning or, preferably, an additional condensate collector can be installed above the equipment.
- The combusted gas discharge pipe must be sufficiently inclined towards the boiler (at least 50 mm per metre) and an adequate condensate collection tank and discharge system constructed (at least 1 m before the boiler opening). The elbows fitted must be at more than 90° to guarantee the provision of an adequate gradient and tightness on the lip rings.

4.9 Installing the outside sensor

4.9.1. Choice of the location

It is important to select a place that allows the sensor to measure the outside conditions correctly and effectively.

Advised positions:

- on one face of the area to be heated, on the north if possible
- half way up the wall in the room to be heated
- under the influence of meteorological variations
- protected from direct sunlight
- easy to access

в

н

Ζ


- A Recommended position
 - Possible position
 - Inhabited height controlled by the sensor
 - Inhabited area controlled by the sensor


Positions to be avoided:


- masked by a building element (balcony, roof, etc.)
- close to a disruptive heat source (sun, chimney, ventilation grid, etc.)

4.9.2. Connecting the outside sensor

Mount the sensor using the screws and dowels provided.







Inserts

Ø4 wood screw

For the connection of the outside temperature sensor, refer to the chapter "Electrical Connections".

4.10 Electrical connections

4.10.1. Control unit

The boiler is fully pre-wired. The mains supply is made via the cable **C** connected to the mains. All other external connections can be made to the connection connectors (low voltage). The main characteristics of the control unit are described in the table below.

Power supply voltage	230 VAC/50Hz
Rating of the main fuse F1 (230 VAC)	6.3 AT
Fuse rating F2 (230 VAC)	2 AT
Fan-DC	27 VDC



CAUTION

Keep to the polarity shown on the terminals: phase (L), neutral (N) and earth \div .



CAUTION

The following components of the appliance are at a voltage of 230 V:

- Boiler pump (Heating circuit).
- Boiler pump (DHW circuit).
- Combined venturi and gas valve unit.
- 3-way valve.
- The majority of components in the control panel and the terminal box.
- Power supply cable.

4.10.2. Recommendations



WARNING

- Only qualified professionnals may carry out electrical connections, always with the power off.
- The boiler is entirely pre-wired. Do not modify the connections inside the control panel.
- Earth the appliance before making any electrical connections.

Make the electrical connections of the boiler according to:

- The instructions of the prevailing standards.
- The instructions on the electrical diagrams provided with the boiler.
- The recommendations in the instructions.




CAUTION

- Separate the sensor cables from the 230 V cables.
- Outside the boiler: Use 2 pipes or cable guides at least 10 cm apart.



4.10.3. Position of the PCBs




Do not connect anything to the terminal block.

4.10.4. Accessing the connection terminal blocks


To access the connection terminal blocks, proceed as follows:

- 1. Unscrew the 2 screws under the front panel by a quarter turn.
- 2. Remove the front panel.

- 3. Open the holding clips located on the sides.
- 4. Tilt the control panel forward.








- 5. Lift the clip located in front of the control panel.
- 6. Lift the control panel cover.

7. Unclip the PCB cover.

4.10.5. Connecting a direct heating circuit




- 2 Connect the outside temperature sensor.
 - Connect a safety thermostat if the heating circuit is for underfloor heating.
 - Remove the bridge.
 - Connect the wires from the safety thermostat to the connector.
 - Do not connect anything to the terminal block.

Settings to be made for this type of installation						
Parameters	Access	Settings to be made	See chapter			
INSTALLATION	Installer level #SYSTEM menu	EXTENDED	■ "Displaying the parameters in extended mode", page 56			
If safety thermostat is connected to BL on the connection terminal block: IN.BL	Installer level #PRIMARY INSTAL.P menu	STOP HEAT	∎ "Professional settings", page 68			

3

4

4.10.6. Connecting two heating circuits



1 2

3

4

CAUTION

Do not connect anything to the DHW pump outlet as the reversal valve is connected to the PCU PCB in the boiler.

- Connect the outside temperature sensor.
- Connect a safety thermostat if the heating circuit is for underfloor heating.

Do not connect anything to the terminal block.

- Remove the bridge.
- Connect the wires from the safety thermostat to the connector.
- (5) Connecting an additional circuit to the AD249 option.

Connect the heating pump (circuit A).




6

If underfloor heating is being used, put a safety thermostat in place after the heating pump. The safety thermostat will shut down the heating pump in the event of overheating.

- D Low loss header.
- (8) Connect the heating pump (circuit **B**).
- (9) Connect the 3-way valve (circuit **B**).
- 1 Do not connect anything to the terminal block.

4.10.7. Hot water storage tank connection (Type PS)



Connect the DHW tank anode.

3

If the tank is not fitted with an impressed current anode, put the simulation connector in place (delivered with the DHW sensor - package AD212).


- PS storage tank.
- **(5)** Solar sensor probe.
- 6 Connect the solar station to the solar collectors.
- ⑦ Do not connect anything to the terminal block.

Settings to be made for this type of installation						
Parameters	Access	Settings to be made	See chapter			
INSTALLATION	Installer level #SYSTEM menu	EXTENDED	■ Tisplaying the parameters in extended mode", page 56			
I.SYST ⁽¹⁾	Installer level #SYSTEM menu	STORAGE TANK	■ Setting the parameters specific to the installation", page 57			
P.DHW: ⁽¹⁾	Installer level #SYSTEM menu	PUMP				
(1) The parameter	is only displayed if IN	STALLATION parameter	is set to EXTENDED			

i

If, during DHW loading, the temperature of the storage tank falls below the primary DHW set point (parameter PRIM.TEMP.DHW), the boiler maintains the latter at temperature to guarantee the loading of the DHW tank The heating zone is maintained at the set temperature calculated according to the outside temperature. The zone is reheated when the heating buffer temperature sensor falls -6°C below the calculated set temperature. Reheating in the heating zone stops when the heating buffer temperature rises above the calculated set temperature.

4.10.8. Pool connection



Settings to be made for this type of installation						
Parameters	Access	Settings to be made	See chapter			
INSTALLATION	Installer level #SYSTEM menu	EXTENDED	■ Tisplaying the parameters in extended mode", page 56			
CIRC. B:	Installer level #SYSTEM menu	SWIM.P.	Setting the parameters specific to the installation", page 57			
If I.TEL: is used I.TEL:	Installer level #SYSTEM menu	0/1 B	, , , , , , , , , , , , , , , , , , ,			
MAX. CIRC. B	Installer level #SECONDARY LIMITS menu	Set the value of MAX.CIRC.B to the temperature corresponding to the needs of the exchanger	■ "Professional settings", page 68			



Controlling the pool circuit

The control system can be used to manage a swimming pool circuit in both cases:

Case 1: The control system regulates the primary circuit (boiler/ exchanger) and the secondary circuit (exchanger/pool).

- Connect the primary circuit pump (boiler/exchanger) to the B outlet on the connection terminal block. The temperature MAX.CIRC.B is then guaranteed during comfort periods on programme B in summer and winter alike.
- Connect the swimming pool sensor (package AD212) to the S DEP B inlet on the connection terminal block.
- Set the set point of the pool sensor using key ↓ in the range 5 -39°C.

Case 2: The pool has already a regulation system that is to be kept. The control system only regulates the primary circuit (boiler/exchanger).

 Connect the primary circuit pump (boiler/exchanger) to the B outlet on the connection terminal block.
 The temperature MAX.CIRC.B is then guaranteed during comfort periods on programme B in summer and winter alike.

1

- The swimming pool can also be connected to circuit **C** by adding the AD249 option:
 - Make the connection to the terminal blocks marked C.
 - Set the parameters for circuit **C**.

Hourly programming of the secondary circuit pump


The secondary pump operates during programme **B** comfort periods in summer and winter alike.

Stopping

To prepare your pool for winter, consult your pool specialist.

4.10.9. Connecting the options

For example: TELCOM voice remote monitoring module, remote controls for circuits ${\bf A}$ and ${\bf B}$




Do not connect anything to the terminal block.

Settings to be made for this type of installation						
Parameters	Access	Settings to be made	See chapter			
INSTALLATION	Installer level #SYSTEM menu	EXTENDED	"Displaying the parameters in extended mode", page 56			
O.PUMP A ⁽¹⁾	Installer level #SYSTEM menu	FAILURE	"Setting the parameters specific to the installation", page 57			
(1) The parameter	is only displayed if IN	STALLATION parameter	is set to EXTENDED			



4.11 Electrical diagram



T001963-D

Р	Power supply	DV	3-way valve	PS	Pressure sensor
SCU-C	control panel PCB	PUMP A	Shunt pump (Central heating)	PSU	Parameter storage for PCBs PCU and SU
S	On/Off switch	HLS	Safety thermostat	PWM PUMP	Modulation signal from the boiler pump
PUMP B	Shunt pump (DHW)	FAN	Fan	DIS	Display
IT	Ignition transformer	TS	Temperature sensor	WS	DHW sensor
E	Ignition power relay	RTS	Return sensor		
GB	Combined venturi and gas valve	FTS	Flow sensor		



4.12 Filling the system

4.12.1. Water treatment

In most cases, the boiler and the central heating installation can be filled with normal tap water and no water treatment will be necessary.



WARNING

Do not add chemical products to the central heating water without first consulting a water treatment professional. For example: antifreeze, water softeners, products to increase or reduce the pH value, chemical additives and/or inhibitors. These may cause faults in the boiler and damage the heat exchanger.



Rinse the central heating installation with at least 3x the volume of the central heating installation. Flush the DHW pipes with at least 20 times the volume of the pipes.

For an optimum functioning of the boiler, the water of the installation must comply with following characteristics:

		Total installed	Total installed heat output (kW)				
		≤ 70	70 - 200	200 - 550	> 550		
Degree of acidity (water non-treated)	рН	7 - 9	7 - 9	7 - 9	7 - 9		
Degree of acidity (water treated)	рН	7 - 8,5	7 - 8,5	7 - 8,5	7 - 8,5		
Conductivity at 25°C	μS/cm	≤ 800	≤ 800	≤ 800	≤ 800		
Chlorides	mg/l	≤ 150	≤ 150	≤ 150	≤ 150		
Other components	mg/l	< 1	< 1	< 1	< 1		
Total water hardness ⁽¹⁾	°f	1 - 35	1 - 20	1 - 15	1 - 5		
	°dH	0,5 - 20,0	0,5 - 11,2	0,5 - 8,4	0,5 - 2,8		
	mmol/l	0,1 - 3,5	0,1 - 2,0	0,1 - 1,5	0,1 - 0,5		

of 8,4 °dH (1,5 mmol/l, 15 °f) applies and for above 200 kW a maximum total water hardness of 2,8 °dH (0,5 mmol/l, 5 °f) applies



If a water treatment is necessary, **De Dietrich Thermique** recommends the following manufacturers:

- Cillit
- Climalife
- Fernox
- Permo
- Sentinel



T001523-B

Filling the siphon

- 1. Remove the siphon.
- 2. Fill the siphon with water. This must be filled up to the level markers.
- 3. Re-assemble the siphon.





4.12.2.

CAUTION

- Fill the water siphon before starting the boiler to avoid combustion products escaping from the boiler.
- Mount the vent hose above the siphon.

4.12.3. Filling the system







CAUTION


Before filling, open the valves on every radiator in the installation.

1. Open the cold water inlet and heating outlet valves.



2. Open the disconnector valves (During filling, air can escape from the system via the automatic air vent).





3. Close the disconnector valves when the manometer indicates a pressure of 2 bar

4. Check the tightness of the water connections.




T001507-B



5 Commissioning

5.1 Control panel




5.1.1. Description of the keys

- A Temperature setting key (heating, DHW, swimming pool)
- **B** Operating mode selection key
- **C** DHW override key

Е

- **D** Key to access the parameters reserved for the installer
 - Keys on which the function varies as and when selections are made
- **F** Rotary setting button:
 - Turn the rotary button to scroll through the menus or modify a value
 - Press the rotary button to access the selected menu or confirm a value modification

5.1.2. Description of the display



Key functions

→	Access to the various menus
Ŵ	Used to scroll through the menus
Ū I	Used to scroll through the parameters
?	The symbol is displayed when help is available
ф	Used to display the curve of the parameter selected
STD	Reset of the time programmes
II	Selection of comfort mode or selection of the days to be programmed
00	Selection of reduced mode or deselection of the days to be programmed
Ļ	Back to the previous level
ESC	Back to the previous level without saving the modifications made
đ	Manual reset

Flame output level

		t
ه ^{bar} ا		Ļ
	, <u>autos) ĉi (⁴, da 14</u> 088888 ? (<u>A</u> 11) [50] d	-



C002703-A


The whole symbol flashes: The burner starts up but the flame is not yet present

Part of the symbol flashes: Output is increasing

Steady symbol: The required output has been reached

Part of the symbol flashes: Output is dropping





Ð

8

₿

D

Ċ

ſſh,

- The solar load pump is running
- The top part of the tank is reheated to the tank set point


The entire tank is reheated to the tank set point

The entire tank is reheated to the solar tank set point

The tank is not loaded - Presence of the solar control system

Operating modes

Solar (If connected)



Ш

- Summer mode: The heating is off. Domestic hot water continues to be produced
- WINTER mode: Heating and domestic hot water working
- AUTO Operation in automatic mode according to the timer programme
 - Comfort mode: The symbol is displayed when a DAY override (comfort) is activated
 - Flashing symbol: Temporary override
 - Steady symbol: Permanent override

Reduced mode: The symbol is displayed when a NIGHT override (reduced) is activated

- Flashing symbol: Temporary override
- Steady symbol: Permanent override


Holiday mode: The symbol is displayed when a HOLIDAY override (antifreeze) is activated

- Flashing symbol: Holiday mode programmed
- Steady symbol: Holiday mode active
- Manual mode

8

<u>ி</u> பே ோ<u>ல</u>

System pressure



bar

llı.

Pressure indicator: The symbol is displayed when a water pressure sensor is connected.

- Flashing symbol: The water pressure is insufficient.
- Steady symbol: The water pressure is sufficient.

Water pressure level


- ▶ .: 0,9 to 1,1 bar
- ▶ ...: 1,2 to 1,5 bar
- ▶ JI: 1,6 to 1,9 bar
- ▶ ...Il: 2,0 to 2,3 bar


Domestic Hot Water override

A bar is displayed when a DHW override is activated:

- Flashing bar: Temporary override
- Steady bar: Permanent override

Other information





₽₹

M

 \bigcirc

The symbol is displayed when domestic hot water production is running.

Valve indicator: The symbol is displayed when a 3-way valve is connected.

- ▶ ► S-way valve opens
- ► IX : 3-way valve closes

The symbol is displayed when the pump is operating.

Name of the circuit for which the parameters are displayed.

- I

٥Å Ô

5.1.3. Access to the various browsing levels

User level

The information and settings in the User level can be accessed by everyone.

1. Press the \rightarrow key.


Installer level

The information and settings in the Installer level can be accessed by experienced people.


1. Press the \rightarrow key.

2. Press the 🛓 key.

It is also possible to access the installer level by pressing only the 🎍 key for around 5 seconds.



SUNDAY 11:45





⇒ Į

िक →

- ≬

MODE

- 62

۵

MODE

<u>AUTO</u>

After Sales level

The After Sales Service information and settings can be accessed by the professional providing the After Sales Service.

1. Press the \rightarrow key.

2. Press key 🔓 for around 5 seconds.

It is also possible to access the After Sales level by pressing only the 🎍 key for around 10 seconds.

5.1.4. Browsing in the menus

 #MEASURES

 #MEASURES

 #MEASURES

 #ITME PROGRAM

 #STITULE PROGRAM

 #STITULE PROGRAM

 #TIME DAY

 AUTO

 AUTO

 Image: Constraint of the state of the sta

בבלבבון הילה הלימה איני הוף הלה הלימי איני איני הלימי איני בליבול בבליבול בבליבול בבליבו

CURRENT P

AUTO

ÛI

ŵ

ألللت بالمتعاطية بتعه تصفه بعك بشتيت تشتيت

TEMP.: 68°

M

AUTO

SUNDAY 11:45

, MORON

SUNDAY 11:45

MODR**O**M


C002219-D-04

C002235-E-04

C002221-C-04

- To select the desired menu, turn the rotary button.
 To access the menu, press the rotary button.
 - To go back to the previous display, press the key \square .
- 3. To select the desired parameter, turn the rotary button.
- To modify the parameter, press the rotary button. To go back to the previous display, press the key ,__.





5.2.1. Preparing the boiler for commissioning



WARNING

Do not put the boiler into operation if the supplied gas is not in accordance with the approved gas types.

Preparatory procedure for boiler commissioning:

- Check that the gas type supplied matches the data shown on the boiler's data plate.
- Check the gas circuit.
- Check the hydraulic circuit.
- Check the water pressure in the heating system.
- Check the electrical connections to the thermostat and the other external controls.
- Check the other connections.
- Test the boiler at full load. Check the setting of the gas/air ratio and, if necessary, correct it.
- Test the boiler at part load. Check the setting of the gas/air ratio and, if necessary, correct it.
- Finalizing work.

5.2.2. Gas circuit



WARNING

Ensure that the boiler is switched off.

- 1. Open the main gas supply.
- 2. Unscrew the two screws located under the front panel by a quarter turn and remove the panel.
- Tilt the control box forwards by opening the holding clips located at the sides.
- 4. Check the gas supply pressure at the pressure outlet **C** on the gas valve unit.



WARNING

To ascertain the gas types permitted, see chapter: "Equipment categories", page 8

- 5. Check the tightness of the gas connections made after the gas valve unit in the boiler.
- 6. Check the tightness of the gas line, including the gas valves. The test pressure must not exceed 60 mbar.
- 7. Purge the gas supply pipe within the boiler by unscrewing the pressure outlet on the gas block. Tighten the measurement point when the pipe has been sufficiently purged.
- 8. Check the tightness of the gas connections in the boiler.

T001518-B

5.2.3. Hydraulic circuit

- Check the condensate discharge siphon; it must be filled with clean water up to the mark.
- Check that there are no leaks on the hydraulic connections.


5.2.4. Electrical connections

• Check the electrical connections.

5.3 Commissioning the boiler

Chec Contrô

- 1. Tilt the control box upwards again and fasten it using the clips located at the sides.
- 2. Open the main gas supply.
- 3. Open the gas valve on the boiler.



4. Turn on the boiler using the on/off switch.

- 5. The first time the boiler is powered up, the **LANGUAGE** menu is displayed. Select the desired language by turning the rotary button.
- 6. To confirm, press the rotary button.

The boiler will begin an automatic venting-programme (which lasts approx. 3 minutes) and will do this every time the power supply is isolated.

Error during the start-up procedure:

- No information is shown on the display:
 - Check the mains supply voltage
 - Check the fuses
 - Check the connection of the power cable to the connector X1 on the PCU PCB
- If there is a problem, the error is displayed on the screen.
 See chapter: "Messages (Code type Bxx or Mxx)", page 94
- i

C002286-C

If a DHW sensor is connected and the anti-legionella function is activated, the boiler starts to heat the water in the DHW tank as soon as the vent programme has been completed. The heating time depends on the size of the DHW installation.

5.4 Gas settings

5.4.1. Adapting to another gas type



WARNING

Only a qualified engineer may carry out the following operations.

The boiler is preset in the factory to operate on natural gas H (G20).

For operation on another group of gases, carry out the following operations:

- Set the air/gas ratio.
 - "Setting the air/gas ratio (Full load)", page 53 "Setting the air/gas ratio (Part load)", page 54
- Set the fan speed using the parameters MIN.VENT., MAX.VENT.BOIL, MAX.VENT.DHW and START SP.:

0

l

MODE

ĥ

See chapter: "Professional settings", page 68

5.4.2. Setting the air/gas ratio (Full load)

- 1. Unscrew the plug of the flue gas measurement point.
- 2. Connect the flue gas analyser.



T001581-A

C002271-F-04

WARNING


Ensure that the opening around the sensor is completely sealed when taking measurements.

3. In the main display, press key **b**. The menu **EMISSION MEASURMENTS** is displayed on the screen.

If an automatic vent cycle is running, it is not possible to perform these operations.

- 4. Turn the rotary button until **PMAX** is displayed. The full load is set.
- 5. Measure the percentage of O_2 or CO_2 in the flue gases (Front panel removed) .

- 6. If this rate does not match the required value, correct the gas/air ratio using the adjustment screw A on the gas valve unit.
- 7. Check the flame through the flame inspection window.
 - The flame must not be detached.



TEMP.: 68°

AUTO

SUNDAY 11:45

MIOROM


5. Commissioning

O₂/CO₂ control and setting values for gas H (G20) at full load

Boiler type	Setting value		Checking	value
	O ₂ (%) CO ₂ (%)		O ₂ (%)	CO ₂ (%)
MCA 25/28 BIC	5,2 ± 0,4	8,8 ± 0,2	5,2 ± 0,5	8,8 ± 0,3

O_2/CO_2 control and setting values for gas L (G25) at full load							
Boiler type	Setting va	lue	Checking value				
	O ₂ (%)	CO ₂ (%)	O ₂ (%)	CO ₂ (%)			
MCA 25/28 BIC	4,9 ± 0,4	8,8 ± 0,2	4,9 ± 0,5	8,8 ± 0,3			

O ₂ /CO ₂ control and setting values for propane (G31) at full load				Diameter of the gas diaphragm (x.xx)	
Boiler type	Setting value		Checking value		Fit the gas restrictor in the gas block
	O ₂ (%)	CO ₂ (%)	O ₂ (%)	CO ₂ (%)	Ømm
MCA 25/28 BIC	5,2 ± 0,3	10,3 ± 0,2	5,2 ± 0,5	10,3 ± 0,3	4,00



ألتلتث باعثه باعاب بإعاب بزهاعة بزهابه بأبتاء بتبتيت بتبتيت

TEMP.: 68°

AUTO

ىسىتىسىتىس**ەتەغەنەمەتەم**ىسىسىس

GENE : BOILER TEMI

CURRENT WIND SPEED

 SUNDAY 11:45

,INTOROM

AUTO => PMIN

PMIN

10µ/ 1850 tr/mir

MO<u>D</u>M

C002271-F-04

C002348-F-04

1

MODE

5.4.3. Setting the air/gas ratio (Part load)

- 1. Unscrew the plug of the flue gas measurement point.
- 2. Connect the flue gas analyser.




WARNING

Ensure that the opening around the sensor is completely sealed when taking measurements.

- In the main display, press key
 <u>h</u>. The menu EMISSION
 <u>MEASURMENTS</u> is displayed on the screen.
 - If an automatic vent cycle is running, it is not possible to perform these operations.

- 4. Turn the rotary button until **PMIN** is displayed. The part load is set.
 - If an automatic vent cycle is running, it is not possible to perform these operations.
- 5. Measure the percentage of O_2 or CO_2 in the flue gases (Front panel removed) .

De Dietrich 📀



- 6. If this rate does not match the required value, correct the gas/air ratio using the adjustment screw B on the gas valve unit.
 - Turn the screw B anticlockwise to obtain a lower CO₂ value.
 - Turn the screw B clockwise to obtain a higher CO₂ value.

7. Check the flame through the flame inspection window.

The flame must be stable and blue in colour with orange particles around the edge of the burner.

O₂/CO₂ control and setting values for gas H (G20) at low speed

L L	Ŭ	U	· · ·	•
Boiler type	Setting value		Checking v	/alue
	O ₂ (%)	CO ₂ (%)	O ₂ (%)	CO ₂ (%)
MCA 25/28 BIC	5,9 ± 0,4	8,4 ± 0,2	5,9 ± 0,4	8,4 ± 0,2

O_2/CO_2 control and setting values for gas L (G25) at low speed				
Boiler type	Setting value		Checking value	
	O ₂ (%)	CO ₂ (%)	O ₂ (%)	CO ₂ (%)
MCA 25/28 BIC	5,6 ± 0,4	8,4 ± 0,2	5,6 ± 0,4	8,4 ± 0,2

O ₂ /CO ₂ control and setting values for propane (G31) at low speed


Boiler type	Setting value		Checking value	
	O ₂ (%)	CO ₂ (%)	O ₂ (%)	CO ₂ (%)
MCA 25/28 BIC	5,8 ± 0,3	9,9 ± 0,2	5,8 ± 0,3	9,9 ± 0,2

i

Repeat the high speed test and the low speed test as often as necessary until the correct values are obtained without having to make additional adjustments.

To exit the mode **EMISSION MEASUREMENTS**, press $-\Box$ several times.






5.4.4. Basic setting for the gas/air ratio

If the gas/air ratio is out of adjustment, the gas valve unit has a basic setting. To do this, proceed as follows:

- 1. Switch off the boiler electrical power supply.
- 2. Close the gas valve on the boiler.
- 3. Remove the air inlet flue on the venturi.
- 4. Unscrew the top connection on the gas valve unit.
- 5. Disconnect the connector located under the fan.
- 6. Release the 2 clips holding the fan/mixing elbow unit in place on the heat exchanger.
- Completely remove the fan/mixing elbow unit.
 For steps 3 to 7 inclusive, see chapter: "Checking the burner and cleaning the heat exchanger", page 87
- 8. Turn the setting screw **A** on the gas valve unit to modify the position of the restrictor.
- 9. Turn the setting screw **B** on the gas valve unit anticlockwise until it matches the front panel.
- 10. Turn the setting screw **B** on the gas valve unit by 6 turns clockwise.
- 11.Follow the procedure in reverse to re-assemble all of the components.

5.5 Checks and adjustments after commissioning



5.5.1. Displaying the parameters in extended mode

The display mode on the control panel is set as standard in such a way as only to show the conventional parameters. It is possible to switch to extended mode by proceeding as follows:

- 1. Access the installer level: Press key 🔓 for around 5 seconds.
- 2. Select the menu **#SYSTEM**.
 - Turn the rotary button to scroll through the menus or modify a value.
 - Press the rotary button to access the selected menu or confirm a value modification.


For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49

3. Set parameter **INSTALLATION** to **EXTENDED**.

C002235-F-04

Installer level - Menu #SYSTEM					
Parameter	Adjustment range	Description	Factory setting	Customer setting	
INSTALLATION	CLASSIC	Displays the parameters of a conventional installation	CLASSIC		
	EXTENDED	Displays all parameters			





•

Regardless of what is done to the keys, the regulator switches back to **CLASSIC** mode after 30 minutes.

5.5.2. Setting the parameters specific to the installation

- 1. Access the installer level: Press key 🔓 for around 5 seconds.
- 2. Select the menu **#SYSTEM**.
 - Turn the rotary button to scroll through the menus or modify a value.
 - Press the rotary button to access the selected menu or confirm a value modification.

For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49

3. Set the following parameters according to the connections made to the PCBs:

Parameter	Adjustment range	Description	Factory setting	Customer setting
CIRC. A: (1)(2)	DIRECT	Use as a direct heating circuit	DIRECT	
	PROGRAM.	Use as an independent programmable outlet		
	H.TEMP	Enables operation of circuit A in summer despite manual or automatic summer shutdown		
	DHW	Connection of a second domestic hot water tank		
	DHW ELEC	Used to control the electrical resistor according to the timer programme on circuit A in summer mode		
	DISAB.	No data for circuit A is displayed		
CIRC. B: ⁽¹⁾	3WV	Connecting a circuit with 3-way valve (For example: Underfloor heating)	3WV	
	SWIM.P.	Using the circuit for pool management		
	DIRECT	Use of circuit in direct heating circuit		
CIRC. C: ⁽¹⁾	3WV	Connecting a circuit with 3-way valve (For example: Underfloor heating)	3WV	
	SWIM.P.	Using the circuit for pool management		
	DIRECT	Use of circuit in direct heating circuit		
O.PUMP A ⁽¹⁾ (2)	CH.PUMP A	Heating pump circuit A: The SA outlet is used to control the pump on circuit A	CH.PUMP A	
	CIRC.AUX	Used to resume the functions of the S.AUX: parameter without adding the PCB + sensor option (Package AD249)		
	DHW LOOP	Used to control the domestic hot water looping pump according to the DHW timer programme and force its operation during an override		
	PRIMARY PUMP	The outlet $\ensuremath{\mathfrak{O}}\xspace A$ is active if a heating demand is present on the secondary pump		
	ORDER BURNER	The outlet $oldsymbol{\mathbb{O}} A$ is active when a burner demand is present		
	FAILURE	The outlet $oldsymbol{\mathbb{D}} A$ is active if an fault is detected		

(3) The parameter is only displayed if the parameter **O.PUMP A** is set to **CIRC.AUX** or the 3-way valve PCB option is connected



Installer level - #SYSTEM menu

Parameter	Adjustment range	Description	Factory setting	Customer setting
P.DHW: ⁽¹⁾	PUMP	Use of a tank load pump on the \mathbb{D} , outlet	RV	
	RV	Use of a reversal valve for DHW production		
BS60 ⁽¹⁾	ON	Small capacity tank	OFF	
	OFF	Large capacity tank		
S.AUX ⁽¹⁾⁽³⁾	DHW LOOP	Use as a domestic loop pump	DHW LOOP	
	PROGRAM.	Use as an independent programmable outlet]	
	PRIMARY PUMP	The outlet SAUX is active if a heating demand is present on the secondary pump		
	ORDER BURNER	The outlet SAUX is active when a burner demand is present		
	DHW	Use of primary circuit of second DHW tank		
	FAILURE	The outlet $oldsymbol{\mathbb{P}}$ AUX is active if an fault is detected		
	DHW ELEC	Used to control the electrical resistor according to the timer programme on circuit AUX in summer mode		
I.SYST ⁽¹⁾	SYSTEM	The inlet sensor is used to connect the common flow sensor of a cascade system	SYSTEM	
	STORAGE TANK	Hot water storage tank affected to heating only		
	DHW STRAT	Using the DHW tank with 2 sensors (top and bottom)		
	ST.TANK+DHW	Hot water storage tank affected to heating and domestic hot water		
O. TEL: ⁽¹⁾	FAILURE	The telephone outlet is closed in the event of failure	FAILURE	
	REVISION	The telephone outlet is closed in the event of revision display		
	DEF+REV	The telephone outlet is closed in the event of failure or revision display		
CT.TEL ⁽¹⁾	CLOSE	See table below.	CLOSE	
	OPEN			



Installer level - #SYSTEM menu


Parameter	Adjustment range	Description	Factory setting	Customer setting
I.TEL: ⁽¹⁾	ANTIFR	Start anti-freeze in boiler command	ANTIFR	
	0/1 A	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit A		
	0/1 B	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit B		
	0/1 A+B	ON or OFF contact: I.TEL: can be used as an]	
		antifreeze activation inlet on circuit A+B		
	0/1 C	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit C		
	0/1 A+C	ON or OFF contact: I.TEL: can be used as an]	
		antifreeze activation inlet on circuit A+C		
	0/1 B+C	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit B+C		
	0/1 A+B+C	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit A+B+C		
	0/1 DHW	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit ECS		
	0/1 A+DHW	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit A+ECS		
	0/1 B+DHW	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit B+ECS		
	0/1 A+B+DHW	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit A+B+ECS		
	0/1 C+DHW	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit C+ECS		
	0/1 A+C+DHW	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit A+C+ECS		
	0/1 B+C+DHW	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit B+C+ECS		
	0/1 AUX	ON or OFF contact: I.TEL: can be used as an		
		antifreeze activation inlet on circuit AUX (S.AUX: if the		
		AD249 option is connected or the parameter O.PUMP		
		A is set to CIRC.AUX) When I.TEL: is not active, the auxiliary circuit (AUX)		
		follows the maximum boiler temperature (parameter		
		BOILER MAX).		

(2) If the pump incorporated in the boiler is used for circuit A (parameter CIRC. A: set to DIRECT), the A outlet is free
 (3) The parameter is only displayed if the parameter O.PUMP A is set to CIRC.AUX or the 3-way valve PCB option is connected

CT.TEL	I.TEL:	contact closed	contact open
CLOSE	ANTIFR	The antifreeze mode is active on all boiler circuits.	The mode selected on the boiler is active.
	0/1 A	The mode selected on the circuit is active.	The antifreeze mode is active on the circuit concerned.
	0/1 B	The mode selected on the circuit is active.	The antifreeze mode is active on the circuit concerned.
	0/1 A+B	The mode selected on the circuits is active.	The antifreeze mode is active on the circuits concerned.
	0/1 C	The mode selected on the circuit is active.	The antifreeze mode is active on the circuit concerned.
	0/1 A+C	The mode selected on the circuits is active.	The antifreeze mode is active on the circuits concerned.
	0/1 B+C	The mode selected on the circuits is active.	The antifreeze mode is active on the circuits concerned.
	0/1 A+B+C	The mode selected on the circuits is active.	The antifreeze mode is active on the circuits concerned.
	0/1 DHW	The mode selected on the DHW circuit is active.	The antifreeze mode is active for the DHW circuit.
	0/1 A+DHW	The mode selected on the circuits is active.	The antifreeze mode is active on the circuits concerned.
	0/1 B+DHW	The mode selected on the circuits is active.	The antifreeze mode is active on the circuits concerned.
	0/1 A+B+DHW	The mode selected on the circuits is active.	The antifreeze mode is active on the circuits concerned.
	0/1 C+DHW	The mode selected on the circuits is active.	The antifreeze mode is active on the circuits concerned.
	0/1 A+C+DHW	The mode selected on the circuits is active.	The antifreeze mode is active on the circuits concerned.
	0/1 B+C+DHW	The mode selected on the circuits is active.	The antifreeze mode is active on the circuits concerned.
	0/1 AUX	 The DAUX outlet on the connection terminal block is active. 	 The DAUX outlet on the connection terminal block is not active.
		 The boiler operates at a set point temperature equal to BOILER MAX. 	 The boiler operates with a set point temperature as a function of the outside temperature.

Influence of the parameter setting CT.TEL on the I.TEL: contact

Influenc	e of the parame	ter setting CT.TEL on the I.TEL: contact	
CT.TEL	I.TEL:	contact closed	contact open
OPEN	ANTIFR	The mode selected on the boiler is active.	The antifreeze mode is active on all boiler circuits.
	0/1 A	The antifreeze mode is active on the circuit concerned.	The mode selected on the circuit is active.
	0/1 B	The antifreeze mode is active on the circuit concerned.	The mode selected on the circuit is active.
	0/1 A+B	The antifreeze mode is active on the circuits concerned	The mode selected on the circuits is active
	0/1 C	The antifreeze mode is active on the circuit concerned.	The mode selected on the circuit is active.
	0/1 A+C	The antifreeze mode is active on the circuits concerned	The mode selected on the circuits is active
	0/1 B+C	The antifreeze mode is active on the circuits concerned	The mode selected on the circuits is active
	0/1 A+B+C	The antifreeze mode is active on the circuits concerned	The mode selected on the circuits is active
	0/1 DHW	The antifreeze mode is active for the DHW circuit.	The mode selected on the DHW circuit is active.
	0/1 A+DHW	The antifreeze mode is active on the circuits concerned	The mode selected on the circuits is active
	0/1 B+DHW	The antifreeze mode is active on the circuits concerned	The mode selected on the circuits is active
	0/1 A+B+DHW	The antifreeze mode is active on the circuits concerned	The mode selected on the circuits is active
	0/1 C+DHW	The antifreeze mode is active on the circuits concerned	The mode selected on the circuits is active
	0/1 A+C+DHW	The antifreeze mode is active on the circuits concerned	The mode selected on the circuits is active
	0/1 B+C+DHW	The antifreeze mode is active on the circuits concerned	The mode selected on the circuits is active
	0/1 AUX	 The DAUX outlet on the connection terminal block is not active. The boiler operates with a set point 	block is active.The boiler operates at a set point temperature
		temperature as a function of the outside temperature.	equal to BOILER MAX .




5.5.3. Naming the circuits and generators

1. Access the installer level: Press key 🚡 for around 5 seconds.

2. Select the menu **#NAMES OF THE CIRCUITS**.

- Turn the rotary button to scroll through the menus or modify a value.
- Press the rotary button to access the selected menu or confirm a value modification.

For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49



3. Select the circuit or generator you wish to rename.

Installer lev	Installer level - Menu #NAMES OF THE CIRCUITS			
Parameter	Description	Name given by the customer		
CIRC. A:	Circuit A			
CIRC. B:	Circuit B			
CIRC. C:	Circuit C			
CIRC.AUX	Auxiliary circuit			
CIRC.DHW	Domestic hot water circuit			
GENE	Generator			

- 4. Turn the rotary button to choose the first character from the list. To confirm, press the rotary button.
- 5. Then press again to enter a second character or turn the rotary button to leave an empty space.
- 6. Choose the other characters in the same way. The input zone may contain up to 6 characters.




To move from one character to another, turn the rotary button. To exit without modifications, press keyesc.

7. To confirm the name, press the rotary button and then turn the button slightly anti-clockwise. When the symbol ← appears, press the rotary button. The name is confirmed.

If the name reaches 6 characters, it is automatically confirmed when the last character is confirmed.

5.5.4. Setting the heating curve



1. Access the installer level: Press key 🔓 for around 5 seconds.

2. Select the menu #SECONDARY INSTAL.P.

- Turn the rotary button to scroll through the menus or modify a value.
 - Press the rotary button to access the selected menu or confirm a value modification.

For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49.

- 3. Select the parameter CIRC. CURVE لللالعه رههة نظيف تتعا تتعا تشتيت ألبليا BUILD.INERTIA CIRC.CURVE B CIRC.CURVE C SCREED DRYING 0.7 No ,I**⊾**i®R00M AUTO ſ'n C002316-E-04 4. To modify the value directly, turn the rotary button. To modify the value by displaying the curve, press key μ . - Į CIRCCURVE B "Slope of the heatcurve of the circuit B" MODE AUTO G, A စ ဦ C002317-D-04 5. To modify the curve, turn the rotary button. 0,7 6. To confirm, press the rotary button. - [To cancel, press keyESC. 75 64 50 MODE **0.7 =** Heating curve set. 20 Ť AUTO ۰ð C002318-B-04 Heating curve without BCT 1 Maximum temperature of the circuit C° 2 Water temperature in the circuit for an outside temperature of 0°C (1) 75 3 DAY set point on the circuit 4 Outside temperature for which the maximum water (2) 50 temperature in the circuit is reached **(5) 1.5** 5 Value of the heating curve Select the parameter CIRC. CURVE ... $(\mathbf{3}) \, \overline{\mathbf{20}}$ C° 0 -16
 - When you modify the heating curve, 2 and 4 are recalculated and repositioned automatically.

15/06/12 - 300022159-001-01



C002319-B

(4)

1)75

(2) 64

(X)50

 $\overline{\mathbf{3}}$ $\overline{\mathbf{20}}$

Heating curve with BCT

ᠿ

2

3

4

(5)

Х

5

07


С002320-В

The **BCT** (Base heat Curve Temperature) parameter allows a minimum operating temperature to be imposed on the heating circuit (this temperature may be constant if the circuit gradient is nil).

- Maximum temperature of the circuit
- Water temperature in the circuit for an outside temperature of 0°C
- DAY set point on the circuit
- Outside temperature for which the maximum water temperature in the circuit is reached
- Value of the heating curve Select the parameter CIRC. CURVE ...
- Value set to the parameter HCZP D

When you modify the heating curve, 2 and 4 are recalculated and repositioned automatically.

5.5.5. Finalizing work



0

-15 (4)


- 1. Remove the measuring equipment.
- 2. Put the flue gas sampling plug back in place.
- 3. Refit the front panel. Tighten the two screws by a quarter turn.
- Raise the temperature in the heating system to approximately 70°C.
- 5. Shut down the boiler.
- 6. After about 10 minutes, vent the air in the heating system.
- 7. Checking the hydraulic pressure. If necessary, top up the water level in the heating system (recommended hydraulic pressure between 1,5 and 2 bar).
- 8. Tick the gas category used on the data plate.
- 9. Complete the checklist.
- 10.Explain the operation of the installation, the boiler and the regulator to the users.
- 11.Inform the user of the periodicity of maintenance work to be carried out. Input the service date and the contact details of the installer.
 See chapter: "Customising maintenance", page 82.

12. Give all the instruction manuals to the user.

Commissioning of the boiler is now complete.

The various boiler parameters are preset in the factory. These factory settings are suitable for the most common heating systems. For other systems and situations, the parameters can be modified.

5.6 Reading out measured values



The various values measured by the appliance are displayed in the **#MEASURES** menu.

- 1. To access user level: Press the \rightarrow key.
- 2. Select the menu **#MEASURES**.
 - Turn the rotary button to scroll through the menus or modify a value.
 - Press the rotary button to access the selected menu or confirm a value modification.

For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49.

User level - Menu #MEASURES				
Parameter	Description	Unit		
OUTSIDE TEMP.	Outside temperature	°C		
ROOMTEMP. A ⁽¹⁾	Room temperature of circuit A	°C		
ROOMTEMP. B ⁽¹⁾	Room temperature of circuit B	°C		
ROOMTEMP. C ⁽¹⁾	Room temperature of circuit C	°C		
BOILER TEMP.	Water temperature in the boiler	°C		
PRESSURE	Water pressure in the installation	bar		
WATER TEMP. ⁽¹⁾	Water temperature in the DHW tank	°C		
INST DWH TEMP. ⁽¹⁾	Instant hot water temperature	°C		
STOR.TANK.TEMP ⁽¹⁾	Water temperature in the storage tank	°C		
DCW TEMPERATURE	Domestic cold water temperature	°C		
SWIMMING P.T.B ⁽¹⁾	Water temperature of the swimming pool on circuit B	°C		
SWIMMING P.T.C ⁽¹⁾	Water temperature of the swimming pool on circuit C	°C		
OUTLET TEMP. B ⁽¹⁾	Temperature of the flow water in circuit B	°C		
OUTLET TEMP. C ⁽¹⁾	Temperature of the flow water in circuit C	°C		
SYSTEM TEMP. ⁽¹⁾	Temperature of the system flow water if multi-generator	°C		
T.DHW BOTTOM ⁽¹⁾	Water temperature in the bottom of the DHW tank	°C		
TEMP.TANK AUX ⁽¹⁾	Water temperature in the second DHW tank connected to the AUX circuit	°C		
DHW A TEMP. ⁽¹⁾	Water temperature in the second DHW tank connected to circuit A	°C		
BACK TEMP	Temperature of the boiler return water	°C		
WIND SPEED	Fan rotation speed	rpm		
POWER	Instantaneous boiler output (0%: Burner off or running at minimum output)	%		
CURRENT (µA)	Ionization current	μA		
NB IMPULS.	Number of burner starts (not restartable) The meter is incremented by 8 every 8 start-ups			
RUNTIME	Number of burner operation hours (not restartable) The meter is incremented by 2 every 2 hours	h		
IN 0-10V ⁽¹⁾	Voltage at input 0-10 V	V		
SEQUENCE	Control system sequence			
CTRL	Software control number			
(1) The parameter is only of	isplayed for the options, circuits or sensors actually connected.			

Į

MODE

5.7 Changing the settings

TEMP.: 68°

N٨

AUTO

SUNDAY 11:45

C002235-F-04

The boiler control panel is set for the most common heating systems. With these settings, practically all heating systems operate correctly. The user or installer can optimise the parameters according to own preferences.

For the user settings, refer to the user instructions.

5.7.1. Language selection

- 1. Access the installer level: Press key 🚡 for around 5 seconds.
- 2. Select the menu **#LANGUAGE**.



- Turn the rotary button to scroll through the menus or modify a value.
- Press the rotary button to access the selected menu or confirm a value modification.

For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49


Installer level - Menu #LANGUAGE		
Adjustment range	Description	
FRANCAIS	Display in French	
DEUTSCH	Display in German	
ENGLISH	Display in English	
ITALIANO	Display in Italian	
ESPANOL	Display in Spanish	
NEDERLANDS	Display in Dutch	
POLSKI	Display in Polish	
РУССКИЙ	Display in Russian	
TÜRK	Display in Turkish	

5.7.2. Calibrating the sensors

- 1. To access user level: Press the \rightarrow key.
- 2. Select the menu **#SETTING**.
- i
- Turn the rotary button to scroll through the menus or modify a value.
- Press the rotary button to access the selected menu or confirm a value modification.


For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49

3. Set the following parameters:



Parameter	Adjustment range	Description	Factory setting	Customer
SUM/WIN	15 to 30 °C	Used to set the outside temperature above which heating will be shut down.	22 °C	setting
		• The heating pumps are shut down.		
		 The burner will only start for domestic hot water needs. 		
	NO	► The symbol appears.		
CALIBR. OUT	NO	Heating is never shut down automatically Outside sensor calibration: Used to	Outoido tomporaturo	
CALIDR. OUT		correct the outside temperature	Outside temperature	
CALIBR. ROOM A (1)(2)		Calibration of the room sensor on circuit A Make this setting 2 hours after switching on, when the room temperature has stabilised	Room temperature of circuit A	
OFFSET ROOM A ⁽¹⁾ (3)	-5.0 to +5.0 °C	Room offset on circuit A: Is used to set a room offset Make this setting 2 hours after switching on, when the room temperature has stabilised	0.0	
ANTIFR. ROOM A	0.5 to 20 °C	Room temperature antifreeze activation on circuit A	6 °C	
CALIBR. ROOM B (2)(1)(4)		Calibration of the room sensor on circuit B Make this setting 2 hours after switching on, when the room temperature has stabilised	Room temperature of circuit B	
OFFSET ROOM B ⁽³⁾ (4)(1)	-5.0 to +5.0 °C	Room offset on circuit B: Is used to set a room offset Make this setting 2 hours after switching on, when the room temperature has stabilised	0.0	
ANTIFR. ROOM B ⁽⁴⁾	0.5 to 20 °C	Room temperature at which the antifreeze mode is activated on circuit B	°C ∂°	
CALIBR. ROOM C (4)(1)(2)		Calibration of the room sensor on circuit C Make this setting 2 hours after switching on, when the room temperature has stabilised	Room temperature of circuit C	
OFFSET ROOM C ⁽⁴⁾ (1)(3)	-5.0 to +5.0 °C	Room offset on circuit C: Is used to set a room offset Make this setting 2 hours after switching on, when the room temperature has stabilised	0.0	
ANTIFR. ROOM C ⁽⁴⁾	0.5 to 20 °C	Room temperature antifreeze activation on circuit C	6 °C	





5.7.3. Professional settings

- 1. Access the installer level: Press key 🔓 for around 5 seconds.
- 2. Set the following parameters:

1

- Turn the rotary button to scroll through the menus or modify a value.
 - Press the rotary button to access the selected menu or confirm a value modification.

For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49.

% % 5000 rpm	Maximum boiler temperature Maximum boiler output during heating Maximum boiler output in DHW Minimum fan speed Maximum fan speed setting in heating	75 °C 100% 100% See table below See table below	
% 5000 rpm	Maximum boiler output in DHW Minimum fan speed	100% See table below	
5000 rpm	Minimum fan speed	See table below	
	•		
'000 rpm	Maximum fan speed setting in heating	See table below	
			1
· ·	Maximum fan speed setting in domestic hot water	See table below	
5000 rpm	Optimum start-up speed setting	See table below	
)%	Minimum pump speed	20 %	
)%	Maximum pump speed	60 %	
))))	000 rpm %	hot water 000 rpm Optimum start-up speed setting % Minimum pump speed	hot water000 rpmOptimum start-up speed settingSee table below%Minimum pump speed20 %%Maximum pump speed60 %

Type of gas used	Parameter	Unit	MCA 25/28 BIC
Gas H (G20)	MIN.VENT.	rpm	1800
(Factory setting)	MAX.VENT.BOIL	rpm	4600
	MAX.VENT.DHW	rpm	6300
	START SP.	rpm	3000
Gas L (G25)	MIN.VENT.	rpm	1800
	MAX.VENT.BOIL	rpm	4300
	MAX.VENT.DHW	rpm	5900
	START SP.	rpm	3000
Propane (G31)	MIN.VENT.	rpm	1800
	MAX.VENT.BOIL	rpm	4300
	MAX.VENT.DHW	rpm	5900
	START SP.	rpm	3000

Installer level - Menu	#SECONDARY LIM	ITS	
Parameter	Adjustment range	Description	Factory setting
MAX.CIRC.A	20 to 95 °C	Maximum temperature (Circuit A)	75 °C
		MAX.CIRC", page 72	
MAX.CIRC.B	20 to 95 °C	Maximum temperature (Circuit B)	50 °C
		MAX.CIRC", page 72	
MAX.CIRC.C	20 to 95 °C	Maximum temperature (Circuit C)	50 °C
		I MAX.CIRC ", page 72	
OUT.ANTIFREEZE	OFF , -8 to +10 °C	Outside temperature at which the installation's antifreeze protection is activated. Below this temperature the pumps are permanently on and the minimum temperatures for each circuit are respected. When NIGHT :STOP is set, the reduced temperature is maintained in each circuit (Menu #SECONDARY INSTAL.P). OFF: Antifreeze protection is not activated	+3 °C
HCZP D A ^{(1) (2)}	OFF , 20 to 90 °C	Curve base temperature in Daytime mode (Circuit A)	OFF
HCZP N A ^{(1) (2)}	OFF , 20 to 90 °C	Curve base temperature in Nighttime mode (Circuit A)	OFF
HCZP D B ^{(1) (2)}	OFF , 20 to 90 °C	Curve base temperature in Daytime mode (Circuit B)	OFF
HCZP N B ^{(1) (2)}	OFF , 20 to 90 °C	Curve base temperature in Nighttime mode (Circuit B)	OFF
HCZP D C ^{(1) (2)}	OFF , 20 to 90 °C	Curve base temperature in Daytime mode (Circuit C)	OFF
HCZP N C ^{(1) (2)}	OFF , 20 to 90 °C	Curve base temperature in Nighttime mode (Circuit C)	OFF
PRIM.TEMP.DHW ⁽¹⁾	50 to 79 °C	Boiler temperature setting if producing domestic hot water	65 °C
(1) The parameter is onl(2) The parameter can b		ATION is set to EXTENDED /e by pressing key 욘.	-

Installer level - Menu #PRIMARY INSTAL.P⁽¹⁾ Parameter Adjustment range Description Factory setting Customer setting BURN.MIN.RUN 0 to 180 seconds Setting the burner minimum operation time (In 30 seconds heating mode) TIMER GENE P. 1 to 30 minutes Maximum post-operation duration of the generator 4 minutes (1) pump STOP HEAT TOTAL STOP **IN.BL**⁽¹⁾ Configuration of the PCU BL inlet If the contact is open, the heating is off. If the parameter P.DHW: is set to RV, DHW production nevertheless remains functional. Automatic restart when the contact closes. TOTAL STOP Configuration of the PCU BL inlet If the contact is open, heating and DHW production are off. Automatic restart when the contact closes. SAFETY MODE Configuration of the PCU BL inlet If the contact is open, the boiler goes into safety lockout. The boiler needs to be reset to restart. **BOIL.INERTIA** 1 to 255 seconds Characterisation of boiler inertia 35 seconds The menu is displayed only if the INSTALLATION parameter is set to EXTENDED



Parameter	Adjustment range	Description	Factory setting	Customer setting
BUILD. INERTIA ⁽¹⁾	0 (10 hours) to 10 (50 hours)	 Characterisation of building's inertia: 0 for a building with low thermal inertia. 3 for a building with normal thermal inertia. 10 for a building with high thermal inertia. Modification of the factory setting is only useful in exceptional cases. 	3 (22 hours)	
CIRC.CURVE A ⁽²⁾	0 to 4	Heating curve of the circuit A CORC. CURVE", page 73	1.5	
ANTICIP.A ⁽¹⁾	0.0 to 10.0	Activation and adjustment of the anticipation time I I I I I I I I I I	NO	
ROOM INFL. A ⁽¹⁾	0 to 10	Influence of room sensor A I COM S.INFL", page 74	3	
CIRC.CURVE B ⁽²⁾	0 to 4	Heating curve of the circuit B C CIRC. CURVE ", page 73	0.7	
ANTICIP.B ⁽¹⁾	0.0 to 10.0	Activation and adjustment of the anticipation time I I I I I I I I I I	NO	
ROOM INFL. B ⁽¹⁾	0 to 10	Influence of room sensor B IROOM S.INFL ", page 74	3	
CIRC.CURVE C ⁽²⁾	0 to 4	Heating curve of the circuit C CONTROL CURVE", page 73	0.7	
ANTICIP.C ⁽¹⁾	0.0 to 10.0	Activation and adjustment of the anticipation time C "ANTICIP.A, ANTICIP.B, ANTICIP.C ", page 73	NO	
ROOM INFL. C ⁽¹⁾	0 to 10	Influence of room sensor C ICO "ROOM S.INFL ", page 74	3	
SCREED DRYING	NO, B, C, B+C	Drying the floor CONTROL SCREED DRYING ", page 73	NO	
START DRYING TEMP ⁽³⁾	20 to 50 °C	Screed drying start temperature	20 °C	
STOP DRYING TEMP ⁽³⁾	20 to 50 °C	Screed drying stop temperature	20 °C	
NB DAYS DRYING ⁽³⁾	0 to 99	Number of days of floor drying	0	

(4) The parameter is only displayed if IN 0-10V is set to ON.
(5) The parameter is only displayed if P.DHW is set to PUMP

(6) If a reversal valve is connected, DHW priority will always be total regardless of the setting.

(7) The parameter is only displayed if **LEG PROTEC** is other than **OFF**

Parameter	Adjustment range	Description	Factory setting	Customer setting
NIGHT ⁽¹⁾	DEC.	The lower temperature is maintained (Night mode)	DEC.	
	STOP	The boiler is stopped (Night mode)		
IN 0-10V	OFF / TEMPERATURE / POWER %	Activating the control at 0-10 V Function 0-10 V", page 75	OFF	
VMIN/OFF 0-10V ⁽¹⁾⁽⁴⁾	0 to 10 V	Voltage corresponding to the instruction set minimum	0.5 V	
VMAX 0-10V ⁽¹⁾⁽⁴⁾	0 to 10 V	Voltage corresponding to the instruction set maximum	10 V	
CONS.MIN 0-10V (1)(4)	0 to 100	Minimum set point temperature or output	5	
CONS.MAX 0-10V (1)(4)	5 to 100	Maximum set point temperature or output	100	
BAND WIDTH ⁽¹⁾	4 to 16 K	Control unit bandwidth for the 3-way valves. Option of increasing the bandwidth if the valves are rapid or of reducing it if they are slow.	12 K	
BOIL/3WV SHIFT ⁽¹⁾	0 to 16 K	Minimum temperature difference between the boiler and the valves	4 K	
H. PUMP DELAY ⁽¹⁾	0 to 15 minutes	Timing of the shutdown of the heating pumps. The timing of heating pump shutdown prevents the boiler overheating.	4 minutes	
HW. PUMP DELAY ⁽¹⁾⁽⁵⁾	2 to 15 minutes	Timing of the shutdown of the domestic hot water pump. The timing of the domestic hot water load pump shutdown prevents the boiler and the heating circuits overheating (Only if a load pump is used).	2 minutes	
ADAPT	ON	Automatic adaptation of the heating curves for each circuit with a room sensor with an influence of >0.	ON	
	OFF	The heating curves can only be modified manually.		
PRIORITY DHW ⁽⁶⁾	TOTAL	Interruption of pool heating and reheating during domestic hot water production.	TOTAL	
	SLIDING	Domestic hot water production and heating on the valve circuits if the available output is sufficient and the hydraulic connection allows.		
	NO	 Heating and domestic hot water production in parallel if the hydraulic connection allows. ▲ Risk of overheating in the direct circuit. 		

The parameter is only displayed if **IN 0-10V** is set to **ON**. (5) The parameter is only displayed if **P.DHW** is set to **PUMP**

(6) If a reversal valve is connected, DHW priority will always be total regardless of the setting.
 (7) The parameter is only displayed if LEG PROTEC is other than OFF

Installer level - Menu #SECONDARY INSTAL.P

Parameter	Adjustment range	Description	Factory setting	Customer setting
LEG PROTEC		The anti legionella function acts to prevent the development of legionella in the dhw tank, these bacteria are responsible for legionellosis.	OFF	
	OFF	Anti-legionella function not activated		
	DAILY	The tank is overheated every day from 4:00 o'clock to 5:00 o'clock		
	WEEKLY	The tank is overheated every Saturday from 4:00 o'clock to 5:00 o'clock		
START.TIM.LEG.P ⁽⁷⁾	00:00 to 23:30	Antilegionella start-up time	4:00 h (Increment: 30 minutes)	
DURAT.LEG.PROTECT(7)	60 to 360 min	Antilegionella running time	60 minutes (Increment: 30 minutes)	
OPTIM. DHW ⁽⁵⁾	OFF	The function is deactivated	OFF	
	BOILER. T.	When, in heating mode, the boiler temperature exceeds PRIM.TEMP.DHW by +3°C and DHW tank needs are not met, the domestic hot water pump starts up		
	SYST.TEMP	When, in heating mode, the system temperature exceeds PRIM.TEMP.DHW by +3°C and DHW tank needs are not met, the domestic hot water pump starts up		
ON.DHW ⁽⁵⁾	OFF	The function is deactivated	OFF	
	BOILER. T.	In DHW mode, the DHW load pump starts up only if the boiler temperature is higher than the WATER TEMP. set point + 5°C		
	SYST.TEMP	In DHW mode, the DHW load pump starts up only if the system temperature is higher than the WATER TEMP. set point + 5°C		

(5) The parameter is only displayed if **P.DHW** is set to **PUMP**

(6) If a reversal valve is connected, DHW priority will always be total regardless of the setting.

(7) The parameter is only displayed if LEG PROTEC is other than OFF


MAX.CIRC...



WARNING

If using underfloor heating, do not modify the factory setting (50 °C). To install this, please consult existing legislation.

- In the case of a direct circuit, connect a safety thermostat to the BL contact.
- In the case of a 3-way valve circuit (B or C), connect a safety thermostat to the TS contact.



CIRC. CURVE ...

х


у

ᠿ

Heating curve circuit A, B or C

- Outside temperature (°C)
 - Water flow temperature (°C)
 - Maximum temperature of the circuit B C

ANTICIP.A, ANTICIP.B, ANTICIP.C



- ① Room temperature instruction Comfort
- 2 Room temperature instruction Low
- ③ Time schedule
- Anticipation time = Accelerated reheating phase

The anticipation function calculates the heating restart time to reach the desired room temperature less 0.5 K at the time programmed for switching to comfort mode.

The start time of the timed programmed corresponds to the end of the accelerated reheating phase.

The function is activated by setting a different **OFF** value.

The value set corresponds to the time considered necessary to return the installation to the required temperature (outside temperature

0°C), starting from a residual room temperature corresponding to the low nocturnal instruction.

Anticipation is optimised if a room sensor is connected. The regulator will automatically fine set the anticipation time.



This function is dependent on the surplus output available in the installation.

SCREED DRYING


Used to force a constant flow temperature or a train to accelerate screed drying on underfloor heating.

The setting for these temperatures must follow the screed-layer's recommendations.

The activation of this parameter (setting other than **OFF**) forces the permanent display of **SCREED DRYING** and deactivates all other functions on the control unit.

When floor drying is active on a circuit, all other circuits (e.g. DHW) are shut down. The use of this function is only possible on circuits B and C.





STOP DRYING TEMP START DRYING TEMP Today NB DAYS DRYING Normal regulation (End of drying) Heating temperature setting (°C)

For example STOP DRYING TEMP: 47 °C START DRYING TEMP: 20 °C NB DAYS DRYING Normal regulation (End of drying) Heating temperature setting (°C)

Every day at midnight (00:00): the set point (**START DRYING TEMP**) is recalculated and the remaining number of days (**NB DAYS DRYING**) is decremented.

ROOM S.INFL

Used to adjust the influence of the room sensor on the water temperature for the circuit concerned.

0	No influence (remote control fitted in a location with no influence)				
1	Slight influence				
3	Average influence (recommended)				
10	Room thermostat type operation				

NIGHT



This parameter is displayed if at least one circuit does not include a room sensor.

For circuits without a room sensor:

- ▶ NIGHT :DEC. (Reduced): The reduced temperature is maintained during reduced periods. The circuit pump operates constantly.
- ► NIGHT :STOP (Stop): Heating is shut down during reduced periods. When installation antifreeze is active, the reduced temperature is maintained during reduced periods.

For circuits with a room sensor:

When the room temperature is lower than the room sensor set point: The reduced temperature is maintained during reduced periods. The circuit pump operates constantly.



When the room temperature is higher than the room sensor set point: Heating is shut down during reduced periods. When installation antifreeze is active, the reduced temperature is maintained during reduced periods.

Function 0-10 V

This function controls the boiler using an external system that includes a 0-10 V output connected to the 0-10 V input. This command imposes a temperature or output instruction on the boiler. It is necessary to ensure that the **BOILER MAX** parameter is higher than **CONS.MAX 0-10V** if the command is on temperature.

1 Flow set point temperature (°C) or output (%) 2 Voltage at input (V) - DC 3 0 V 4 CONS.MIN 0-10V 5 CONS.MAX 0-10V VMIN/OFF 0-10V 6 7 **VMAX 0-10V** 8 10 V Х Voltage at input Boiler temperature or sliding output У

If the input voltage is less than **VMIN/OFF 0-10V**, the boiler is off. The boiler temperature setting corresponds strictly to the 0-10 V input. The secondary boiler circuits continue to operate but have no impact on the water temperature in the boiler. If using the 0-10 V input and a secondary boiler circuit, the external regulator providing this 0-10 V power supply must always request a temperature at least equal to the needs of the secondary circuit.

5.7.4. Configuring the network

1. Access the installer level: Press key 🔓 for around 5 seconds.


2. Select the menu **#NETWORK**.


1

- Turn the rotary button to scroll through the menus or modify a value.
- Press the rotary button to access the selected menu or confirm a value modification.

For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49

3. Set the following parameters:






Installer level - Menu #NETWORK ⁽¹⁾					
Parameter	Adjustment range	Description	Factory setting	Customer setting	
CASCADE:	ON / NO	ON : System in cascade	NO		
VM NETWORK ⁽²⁾		Specific menu: Enlist VMs in cascade mode			
		■ See chapter: "Connecting VM iSystem in cascade", page 78			
MASTER CONTROLLER (3)	ON / NO	Configure this control system as master on the bus	ON		
SYSTEM NETWORK ⁽⁴⁾		Specific menu: Enlist generators or VMs in cascade mode			
		See chapter: "Connecting VM iSystem in cascade", page 78			
FUNCT ⁽⁴⁾	CLASSIC	Operation in cascade: Successive triggering of the various boilers in the cascade according to requirements	CLASSIC		
	PARALLEL	Functioning in parallel cascade: If the outside temperature is lower than the value PARALLEL CASC. , all of the boilers are started up at the same time			
PARALLEL CASC. ⁽⁵⁾	-10 to 20 °C	Outside temperature triggering all stages in parallel mode	10 °C		
TIMER GENE P. CASC ⁽³⁾	0 to 30 min	Minimum duration of post-operation of the generator pump	0 mn		
INTER STAGE TIMER ⁽³⁾	1 to 30 min	Time delay for starting up or shutting down generators.	4 mn		
SLAVE NUMBER ⁽⁶⁾	2 to 10	Set the network address of the secondary generator	2		
 The menu is displayed only The parameter is only displation 	ayed if CASCADE: is se ayed if CASCADE: is se ayed if MASTER CONT ayed if FUNCT is set to	et to NO et to ON ROLLER is set to ON PARALLEL			

User level - Menu #SETTING							
Parameter	Adjustment range	Description	Factory setting	Customer setting			
PERMUT ⁽¹⁾	AUTO / 1 10	 This parameter is used to set the master boiler. AUTO: The master boiler switches automatically every 7 days 1 10: The master boiler is always the one 	AUTO				
(1) The paran	1 10: The master boiler is always the one defined by this value Control LER on ON						

Connecting appliances in cascade

It is possible, in a cascade configuration, to enlist generators and/or VM iSystem as slaves. Proceed as follows:

1. Set parameter CASCADE: to ON.





Connecting VM iSystem in cascade


It is possible to assign VMs only as slaves. Proceed as follows:

- 1. Select **VM NETWORK** and press the rotary button to go to the specific menu.
- 2. The screen displayed is used to select the numbers of the slave VMs to be added to the network. Numbers 20 to 39 are dedicated to the VMs. Turn the rotary button to scroll through the numbers and press to confirm the number chosen. Press , _ to go back to the previous list.
- 3. To remove a slave VM from the network, select **DELETE VM**.
- 4. The screen displayed is used to select the numbers of the slave VMs to be removed from the network. Turn the rotary button to scroll through the numbers and press to remove the number chosen. Press ... to go back to the previous list.


5.7.5. Return to the factory settings

To reset the appliance, proceed as follows:

- Press key 1, → and . ⇒ simultaneously for 4 seconds. The menu #RESET is displayed.
- 2. Set the following parameters:



Menu #RESET				
Choice of generator	Parameter		Description	
GENERATOR	RESET	TOTAL	Performs a TOTAL RESET of all parameters	
		EXCEPT PROG.	Performs a parameter RESET but retains the timer programmes	
		PROG.	Performs a RESET on the timer programmes but retains the parameters	
		SENSOR SCU	Performs a RESET of the generator sensors connected	
		ROOM SENSOR	Performs a RESET of the room sensors connected	



After reset (**TOTAL RESET** and **RESET EXCEPT PROG.**), the control system goes back to the display of the language choice after a few seconds.

- 1. Select the desired language by turning the rotary button.
- 2. To confirm, press the rotary button.



6 Switching off the boiler

6.1 Installation shutdown



CAUTION

Do not switch off the mains supply to the appliance. If the central heating system is not used for a long period, we recommend activating the **HOLIDAYS** mode (to ensure the anti-grip of the heating pump).

6.2 Frost protection

When the heating water temperature in the boiler falls by too much, the integrated protection system in the boiler starts up. This protection functions as follows:

- If the water temperature is lower than 7°C, the heating pump starts up.
- ▶ If the water temperature is lower than 4°C, the boiler starts up.
- If the water temperature is higher than 10°C, the boiler shuts down and the circulation pump continues to run for a short time.
- If the water temperature in the storage tank is less than 7°C, it is reheated to its set point.



CAUTION

- The antifreeze protection does not function if the appliance is switched off.
- The integrated protection system only protects the boiler, not the installation. To protect the installation, set the appliance to HOLIDAYS mode.

The **HOLIDAYS** mode protects:

- The installation if the outside temperature is lower than 3°C (factory setting).
- The room temperature if a remote control is connected and the room temperature is lower than 6 °C (factory setting).
- The domestic hot water tank if the tank temperature is lower than 4 °C (the water is reheated to 10 °C).

To configure the holidays mode: **I** Refer to the user instructions.

7 Checking and maintenance

7.1 General instructions



- WARNING
 - Maintenance operations must be done by a qualified engineer.
 - An annual inspection is compulsory.
 - Only original spare parts must be used.
- Have the flues swept at least once a year or more, depending on the regulations in force in your country.
 See chapter: "Chimney sweep instructions", page 81
- Carry out the inspection and standard maintenance operations once a year.

See chapter: "Standard inspection and maintenance operations", page 83

Carry out specific maintenance operations if necessary.
 See chapter: "Specific maintenance operations", page 88

7.2 Chimney sweep instructions



CAUTION

Have the flues swept **at least once a year** or more, depending on the regulations in force in your country. Only a qualified engineer may carry out the following operations.

- 1. Press the 🛓 key.
- Check the combustion each time the flues are swept. See chapter: "Setting the air/gas ratio (Full load)", page 53 + "Setting the air/gas ratio (Part load)", page 54
- 3. To go back to the main display, press key $\square 2$ times.

Menu #EMISSION MEASUREMENTS					
Generator	Function available	Description	Values displaye	d	
Generator name	AUTO	normal operation	BOILER TEMP. CURRENT WIND SPEED BACK TEMP	°C µA rpm °C	
	PMIN	Operating at minimum output	BOILER TEMP. CURRENT WIND SPEED BACK TEMP	°C µA rpm °C	
	PMAX	Operating at maximum output	BOILER TEMP. CURRENT WIND SPEED BACK TEMP	°C µA rpm °C	

7.3 Customising maintenance

7.3.1. Maintenance message

The boiler incorporates a function that can be used to display a maintenance message. To set the parameters for this function, proceed as follows:


- Access the "After Sales" level: Hold down the key until #PARAMETERS is displayed.
- 2. Select the menu **#REVISION**.

- Turn the rotary button to scroll through the menus or modify a value.
 - Press the rotary button to access the selected menu or confirm a value modification.

For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49

3. Set the following parameters:

Parameter	Adjustment range	Description
TYPE	NO	Factory setting No message indicating that maintenance is necessary
	MANU	Recommended setting Signals that maintenance is necessary on the date selected. Set the date using the parameters below.
	AUTO	▲ Not applicable. Do not select this setting.
REVISION HOUR ⁽¹⁾	0 to 23	Time at which the REVISION display appears
REV. YEAR ⁽¹⁾ 2008 to 2099		Year in which the REVISION display appears
REVIS. MONTH ⁽¹⁾	1 to 12	Month in which the REVISION display appears
REVISION DATE ⁽¹⁾ 1 to 31		Day on which the REVISION display appears
(1) The parameter is or	ly displayed if MANU is	configured.



After Sales level - Menu #REVISION



Clearing the maintenance message:

After carrying out the maintenance operations, modify the date in the **#REVISION** menu to clear the message.

In the event of maintenance before the maintenance message is displayed:

After carrying out early maintenance operations, it is necessary to set a new date in the **#REVISION** menu.

7.3.2. Contact details of the professional for After Sales Support

In order to assist the user if an error or service message is displayed, it is possible to provide the contact details of the professional to be contacted. To input the professional's contact details, proceed as follows:

- Access the "After Sales" level: Hold down the key until #PARAMETERS is displayed.
- 2. Select the menu **#SUPPORT**.

- Turn the rotary button to scroll through the menus or modify a value.
- Press the rotary button to access the selected menu or confirm a value modification.

For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49

3. Set the following parameters:

After Sales level - Menu #SUPPORT				
Parameter Description				
NAME Input the installer's name				
TELEPHONE NUM.	Input the installer's telephone number			


When the message **REVISION** is displayed, press **?** to display the professional's telephone number.

C002302-D-04

7.4 Standard inspection and maintenance operations



During inspection and maintenance operations, always replace all gaskets on the parts removed.



OM.FAIL D27

22

SUNDAY 11.45

- 1

MODE

<u>G</u>

၀ ဦ



7.4.1. Checking the hydraulic pressure

The hydraulic pressure must reach a minimum of 0,8 bar. If the hydraulic pressure is lower than 0,8 bar, the symbol **bar** flashes.



If necessary, top up the water level in the heating system (recommended hydraulic pressure between 1,5 and 2 bar).

7.4.2. Checking the expansion vessel

Check the expansion vessel and replace it if necessary.

7.4.3. Checking the ionization current

The ionization current is displayed in the menu **#MEASURES**.

See chapter: "Reading out measured values", page 65


7.4.4. Checking the transfer capacity


If the transfer capacity is particularly weak (temperature too low and/ or flow rate less than 6,2 l/min), clean the plate exchanger (domestic hot water end).

See chapter: "Cleaning the plate exchanger", page 89

7.4.5. Checking the tightness of the flue gas evacuation and air inlet connections

Check the tightness of the flue gases evacuation and air inlet connections.





7.4.6. Checking combustion

The check on combustion is done by measuring the percentage of O_2/CO_2 in the flue gas discharge flue. To do this, proceed as follows:

- 1. Unscrew the plug of the flue gas measurement point.
- 2. Connect the flue gas analyser.




CAUTION

Ensure that the opening around the sensor is completely sealed when taking measurements.

- 3. Set the boiler to full load. See chapter: "Setting the air/gas ratio (Full load)", page 53. The boiler is now operating at full load. Measure the percentage of CO₂ and compare this value with the checking values given.
- 4. Set the boiler to part load. See chapter: "Setting the air/gas ratio (Part load)", page 54. The boiler is now operating on part load. Measure the percentage of CO₂ and compare this value with the checking values given.





7.4.7. Checking the automatic air vent


- 1. Switch off the boiler electrical power supply.
- 2. Close the gas valve on the boiler.
- 3. Close the main gas inlet valve.
- 4. Unscrew the two screws located under the front panel by a quarter turn and remove the panel.
- 5. Tilt the control box forwards by opening the holding clips located at the sides.
- 6. Check whether there is any water in the small hose on the automatic air vent.
- 7. If any leaks are detected, replace the air vent.

7.4.8. Checking the safety valve

- 1. Take out the flow collector located under the boiler.
- 2. Check whether there is any water in the end of the flow pipe on the safety valve.
- 3. If any leaks are detected, replace the safety valve.

7.4.9. Checking the siphon

- 1. Remove the siphon and clean it.
- 2. Fill the siphon with water.
- 3. Put the siphon back in place.



7.4.10. Checking the burner and cleaning the heat exchanger

CAUTION

During inspection and maintenance operations, always replace all gaskets on the parts removed.

- 1. Remove the air inlet flue on the venturi.
- 2. Unscrew the top connection on the gas valve unit.
- 3. Disconnect the connector located under the fan.
- 4. Release the 2 clips holding the fan/mixing elbow unit in place on the heat exchanger.
- 5. Completely remove the fan/mixing elbow unit.
- 6. Tilt the burner and remove it, along with the heat exchanger gasket.
- 7. Use a vacuum cleaner fitted with a special endpiece (accessory) to clean the top part of the heat exchanger (combustion chamber).
- 8. Thoroughly clean with the vacuum cleaner again without the top cleaning brush on the endpiece.
- 9. Check (using a mirror, for example) whether any dust can still be seen. If so, hoover it up.
- 10. The burner does not require any maintenance, it is self-cleaning. Check that there are no cracks and/or other tears on the surface of the dismantled burner. If this is not the case, replace the burner.
- 11. Checking the ignition electrode / ionization sensor.

12.To re-assemble, perform the above actions in reverse order.

CAUTION

- Remember to reconnect the connector to the fan.
- Check that the gasket is correctly positioned between the mixing elbow and the heat exchanger. (Completely flat in the appropriate groove means it is leak proof).

13.Open the gas inlet valves and switch on the mains supply to the boiler.



7.5 Specific maintenance operations

If the standard inspection and maintenance operations have revealed the necessity to carry out additional maintenance work, proceed as follows, depending on the nature of the work:


7.5.1. Replacing the ionization/ignition electrode


Replace the ionization/ignition electrode in the following cases:

- ► Ionization current <3 µA.
- Electrode worn.

If replacement is necessary, proceed as follows:

- 1. Remove the cable from the ionization/ignition electrode on the ignition transformer.
- 2. Unscrew the 2 screws and remove the ionization/ignition electrode.
- 3. Replace the ionization/ignition electrode.





7.5.2. Cleaning the plate exchanger

Depending on the water quality and the operating mode, limescale deposits may form in the plate exchanger. Periodic descaling may therefore be necessary. As a general rule, a periodic inspection, along with cleaning, if necessary, is sufficient. The following factors may affect the periodicity:

- Water hardness.
- Composition of the limescale.
- Number of hours' operation of the boiler.
- Draw-off rate.
- Domestic hot water set point temperature.

If descaling of the plate exchanger is necessary, proceed as follows:

- 1. Close the main water valve.
- 2. Drain the boiler.




WARNING


To drain the boiler tanks, see chapter: "Replacing the boiler tanks", page 90


- 3. Remove the air vent hose above the siphon.
- 4. Remove the siphon.
- 5. Remove the clip holding the heating flow hose in place on the left side of the hydroblock.
- 6. Dismantle the heating flow hose on the left side of the hydroblock and not on the heat exchanger side (heating circuit).
- 7. Unscrew the 2 hexagonal socket screws located to the right and left of the plate exchanger.
- 8. Slightly turn the plate exchanger and carefully remove it from the boiler.
- 9. Clean the plate exchanger with a descaling product (e.g. citric acid with a pH of approximately 3). To do this, a specific cleaning appliance is available as an accessory. After cleaning, rinse thoroughly under running water.

10.Re-assemble all of the components.









7.5.3. Replacing the boiler tanks


Replace the boiler tanks when they are defective. To do this, proceed as follows:

- 1. Close the main water valve.
- 2. Remove the air vent hose above the siphon.
- 3. Remove the siphon.
- 4. Remove the clip holding the plug in place.
- 5. Remove the plug.

6

- 6. Open the drainage valve on the tank hydroblock to drain the boiler tanks.
- 7. Unscrew the connection on the domestic hot water outlet.
- 8. Unscrew the connection on the pipe that links the hydroblock to the boiler tanks.
- 9. Remove the pipes connected to the boiler tanks.
- 10.Remove the DHW sensors from the tanks and disconnect the cables.
- 11.Disconnect the instrument box cable from the tanks.
- 12.Unscrew the 4 screws located on the front and back of the boiler tanks.
- 13.Remove the boiler tanks with the left-hand section of the insulation.
- 14.To re-assemble, perform the above actions in reverse order.





7.5.4. Replacing the 3-way valve

If it becomes necessary to replace the 3-way valve, proceed as follows:

- 1. Close the main water valve
- 2. Drain the boiler.
- 3. Remove the air vent hose above the siphon.
- 4. Remove the siphon.
- 5. Remove the clip holding the heating return hose in place on the right side of the hydroblock.
- 6. Remove the heating return hose on the right side of the hydroblock and not on the heat exchanger side (heating circuit).
- 7. Unplug the actuator.
- 8. Remove the clip holding the 3-way valve in place.
- 9. Remove the 3-way valve.




Lift and rotate by a quarter turn.

10. Proceed as for dismantling in reverse.



CAUTION


Be careful of the positioning cams on the 3-way valve.



7.5.5. Replacing the non-return valve

Replace the nonreturn valve when faulty or when the maintenance kit contains one. To do this, proceed as follows:

- 1. Remove the air inlet flue on the venturi.
- 2. Unscrew the top connection on the gas valve unit.
- 3. Disconnect the connector located under the fan.
- 4. Release the 2 clips holding the fan/mixing elbow unit in place on the heat exchanger.
- 5. Completely remove the fan/mixing elbow unit.
- 6. Replace the non-return valve located between the mixing elbow and the fan.
- 7. To re-assemble, perform the above actions in reverse order.







C002434-A



T001523-B

7.5.6. Assembling the boiler

1. Follow the procedure in reverse to re-assemble all of the components.



CAUTION

During inspection and maintenance operations, always replace all gaskets on the parts removed.

- 2. Fill the siphon with clean water up to the mark.
- 3. Put the siphon back in place.



CAUTION

Mount the vent hose above the siphon.

- 4. Carefully open the main water valve, fill the installation, vent it and, if need be, top it up with water.
- 5. Check the seals on the gas and water connections.
- 6. Switch the boiler back on.



8 Troubleshooting

8.1 Anti-hunting

When the boiler is in Anti-short-cycle operating mode, the symbol **?** flashes.

1. Press the "?" key.

The message **Operation assured when the restart temperature will be reached** is displayed.



This message is not an error message but an item of information.

8.2 Messages (Code type Bxx or Mxx)

In the case of failure, the control panel displays a message and a corresponding code.

- Make a note of the code displayed. The code is important for the correct and rapid diagnosis of the type of failure and for any technical assistance that may be needed.
- Switch the boiler off and switch back on. The boiler starts up again automatically when the reason for the blocking has been removed.
- 3. If the code is displayed again, correct the problem by following the instructions in the table below:

Code	Messages	Description	Checking / solution
B00	BL.CRC.PSU	The PSU PCB is incorrectly configured	 Parameter error on the PSU PCB Set the type of generator again in the menu #CONFIGURATION (Refer to the original rating plate)
B01	BL.MAX BOILER	Maximum flow temperature exceeded	The water flow in the installation is insufficientCheck the circulation (direction, pump, valves)
B02	BL.HEATING SPEED	The increase in flow temperature has exceeded its maximum limit	 The water flow in the installation is insufficient Check the circulation (direction, pump, valves) Check the water pressure Check the cleanliness of the heat exchanger Sensor error Check that the sensors are operating correctly Check whether the boiler sensor has been correctly fitted

Code	Messages	Description	Checking / solution
B07	BL.DT OUTL RET.	Maximum difference between	The water flow in the installation is insufficient
		the flow and return	 Check the circulation (direction, pump, valves)
		temperature exceeded	 Check the water pressure
			 Check the cleanliness of the heat exchanger
			Sensor error
			• Check that the concerts are operating correctly
			 Check that the sensors are operating correctly Check whether the beiler sensor has been correctly fitted
B08	BL.RL OPEN	The RL inlet on the PCU PCB	 Check whether the boiler sensor has been correctly fitted Parameter error
	DE.ILE OF EN	terminal block is open	
			 Set the type of generator again in the menu #CONFIGURATION (Refer to the original rating plate)
			Bad connection
			Check the wiring
B09	BL.INV. L/N	Set the type of generator again plate)	n in the menu #CONFIGURATION (Refer to the original rating
B10	BL.BL INPUT OPEN	The BL inlet on the PCU PCB	The contact connected to the BL inlet is open
B11		terminal block is open	Check the contact on the BL inlet
			Parameter error
			Check the parameter IN.BL
			Bad connection
			Check the wiring
B13	BL. PCU COM	Communication error with the	Bad connection
	BL.COM PCU-D4	SCU PCB	Check the wiring
			SCU PCB not installed in the boiler
B14	BL.WATER MIS.	The water pressure is lower	Install an SCU PCB Not enough water in the circuit
		than 0,8 bar	
B15	BL.GAS PRESS	Gas pressure too low	 Top up the installation with water Incorrect setting of the gas pressure switch on the SCU PCB
	DE.GAS FILESS	Gas pressure too low	
			 Check that the gas valve is fully opened
			 Checking the gas supply pressure
			 Check whether the gas pressure control system has been correctly fitted
			 Replace the gas pressure control system if need be
B16	BL.BAD SU	The SU PCB is not recognised	Wrong SU PCB for this boiler
			Replace the SU PCB
B17	BL.PCU ERROR	The parameters saved on the	Parameter error on the PCU PCB
		PCU PCB are impaired	Replace the PCU PCB
B18	BL.BAD PSU	The PSU PCB is not	Wrong PSU PCB for this boiler
		recognised	Replace the PSU PCB
B19	BL.NO CONFIG	The boiler has not been	The PSU PCB has been changed
		configured	 Set the type of generator again in the menu
			#CONFIGURATION (Refer to the original rating plate)
B21	BL. COM SU	Communication error between	Bad connection
		the PCU and SU PCBs	 Check that the SU PCB has been correctly put in place on the PCU PCB
			Replace the SU PCB

Code	Messages	Description	Checking / solution
B22	BL.FLAME LOS	No flame during operation	No ionization current
			Purge the gas supply to remove air
			 Check that the gas valve is fully opened
			Check the supply pressure
			 Check the operation and setting of the gas valve unit
			• Check that the air inlet and flue gas discharge flues are
			not blocked
DOS			Check that there is no recirculation of flue gases
B25 B26	BL.SU ERROR BL.DHW. S.	Internal error on the SU PCB	Replace the SU PCB
D20	BL.DHW. 3.	The DHW tank sensor is disconnected or short circuited	 Set the type of generator again in the menu #CONFIGURATION (See nameplate)
			 Check that the sensor is actually connected to the P.DHW inlet on the SCU
			 Check the Ohmic value of the sensor. Replace it if necessary
			Check the wiring
B27	BL.DHW INST	The sensor on the plate exchanger outlet is	 Set the type of generator again in the menu #CONFIGURATION (See nameplate)
		disconnected or short circuited	 Check that the sensor is actually connected to the X20 inlet on the PCU
			 Check the Ohmic value of the sensor. Replace it if necessary
			Check the wiring
M04	REVISION	A service is required	The date programmed for the service has been reached
			 Carry out maintenance on the boiler
			 To clear the inspection, programme another date in the menu #REVISION or set the parameter REVISION TYPE to OFF
M05	REVISION A	An A, B or C service is required	The date programmed for the service has been reached
M06	REVISION B		 Carry out maintenance on the boiler
M07	REVISION C		➤ To clear the inspection, press key ^b
M20	DISGAS	A boiler vent cycle is underway	Switching the boiler on
			 Wait 3 minutes
	FL.DRY.B XX DAYS	Floor drying is active	Floor drying is underway. Heating on the circuits not concerned
	FL.DRY.C XX DAYS	XX DAYS = Number of days'	is shut down.
	FL.DRY.B+C XX DAYS	floor drying remaining.	 Wait for the number of days shown to change to 0
			Set the parameter SCREED DRYING to OFF
M23	CHANGE OUTSI.S	The outside temperature sensor is defective.	Change the outside radio temperature sensor.
M30	BL.COM.MODBUS	No communication with the master regulation by the network MODBUS.	Check the wiring between the module and the master appliance.
M31	BL.SYSTEM NETWORK	Incorrect configuration of the network MODBUS.	 Check that the address of the appliance is correctly configured in the #NETWORK menu.
			 Check that the cascade configuration is set correctly on the master module.
	STOP N XX	The shutdown is active XX = Number of the active	A shutdown is underway. The circuits selected for this stop are in Antifreeze mode during the period chosen.
		shutdown	 Wait until the end date has been passed
			• Set the parameter STOP NXX to OFF

Į

MODE

· Ca

۵

0

tPi

8.3 Message history

التلتيك بالعيامة بإصلية بالمتية بالمتر التلاك التكالية المتكافية المتعال المتعال والمتعال والمتعال والمتعال وال

TEMP.: _ _ _

M

Ē.

BL.HEATING SPEED BL.WATER MIS.

BL.RL OPEN BL.FLAME LOS

Û

BL INPUT OPEN M21 28/08/2008 - 13h32 NUMBER OF CASE OUTSIDE TEMP.

OUTLET TEMP.B

Û

AUTO

ſΡ

AUTO

SUNDAY 11-45

21/10

C002272-C-04

C002381-B-04

The menu (#MESSAGE HISTORIC) is used to consult the last 10 messages displayed by the control panel.

- Access the "After Sales" level: Hold down the key until #PARAMETERS is displayed.
- 2. Select the menu (#MESSAGE HISTORIC).
 - Turn the rotary button to scroll through the menus or modify a value.
 - Press the rotary button to access the selected menu or confirm a value modification.

For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49

3. The list of the last 10 messages is displayed.

4. Select a message to consult the information pertaining to it.



1.0 °C 12.0°C


 Implication
 Implication

In the event of operational failure, the control panel flashes and displays an error message and a corresponding code.

- Make a note of the code displayed. The code is important for the correct and rapid diagnosis of the type of failure and for any technical assistance that may be needed.
- 2. Press the bild key. If the code is displayed again, switch off the boiler and then switch it back on.

C002604-B-04





- 3. Press the **?** key. Follow the instructions displayed to solve the problem.
- 4. Consult the meaning of the codes in the table below:

C002302-D-04

Code	Faults	Cause of the fault	Description	Checking / solution
L00	PSU FAIL	PCU	PSU PCB not connected	 Bad connection Check the wiring between the PCU and PSU PCBs PSU PCB faulty
L01	PSU PARAM FAIL	PCU	The safety parameters are incorrect	 Replace the PSU PCB Bad connection Check the wiring between the PCU and PSU PCBs PSU PCB faulty Replace the PSU PCB
L02	DEF.OUTLET S.	PCU	The boiler flow sensor has short-circuited	 Bad connection Check the wiring between the PCU PCB and the sensor Check that the SU PCB is correctly in place Check that the sensor has been correctly fitted Sensor fault Check the Ohmic value of the sensor Replace the sensor if necessary
L03	DEF.OUTLET S.	PCU	The boiler flow sensor is on an open circuit	 Bad connection Check the wiring between the PCU PCB and the sensor Check that the SU PCB is correctly in place Check that the sensor has been correctly fitted Sensor fault Check the Ohmic value of the sensor Replace the sensor if necessary

Code	Faults	Cause	Description	Checking / solution
		of the fault		
L04	DEF.OUTLET S.	PCU	Boiler temp too low	Bad connection
				 Check the wiring between the PCU PCB and the sensor
				• Check that the SU PCB is correctly in place
				Check that the sensor has been correctly fitted
				Sensor fault
				• Check the Ohmic value of the sensor
				 Replace the sensor if necessary
				No water circulation
				 Vent the air in the heating system
				• Check the circulation (direction, pump, valves)
				Check the water pressure
				 Check the cleanliness of the heat exchanger
L05	STB OUTLET	PCU	Boiler temperature too high	Bad connection
				 Check the wiring between the PCU PCB and the sensor
				Check that the SU PCB is correctly in place
				Check that the sensor has been correctly fitted
				Sensor fault
				• Check the Ohmic value of the sensor
				 Replace the sensor if necessary
				No water circulation
				 Vent the air in the heating system
				 Check the circulation (direction, pump, valves)
				Check the water pressure
				Check the cleanliness of the heat exchanger
L06	BACK S.FAILURE	PCU	The return temperature sensor	Bad connection
			has short-circuited	 Check the wiring between the PCU PCB and the sensor
				Check that the SU PCB is correctly in place
				 Check that the sensor has been correctly fitted
				Sensor fault
				• Check the Ohmic value of the sensor
				 Replace the sensor if necessary
L07	BACK S.FAILURE	PCU	The return temperature sensor	Bad connection
			is on an open circuit	 Check the wiring between the PCU PCB and the sensor
				• Check that the SU PCB is correctly in place
				• Check that the sensor has been correctly fitted
				Sensor fault
				 Check the Ohmic value of the sensor
				 Replace the sensor if necessary

Code	Faults	Cause of the fault	Description	Checking / solution
L08	BACK S.FAILURE	PCU	Return temperature too low	 Bad connection Check the wiring between the PCU PCB and the sensor Check that the SU PCB is correctly in place Check that the sensor has been correctly fitted Sensor fault Check the Ohmic value of the sensor Replace the sensor if necessary No water circulation Vent the air in the heating system Check the circulation (direction, pump, valves) Check the water pressure
L09	STB BACK	PCU	Return temperature too high	 Check the cleanliness of the heat exchanger Bad connection Check the wiring between the PCU PCB and the sensor Check that the SU PCB is correctly in place Check that the sensor has been correctly fitted Sensor fault Check the Ohmic value of the sensor Replace the sensor if necessary No water circulation Vent the air in the heating system Check the value of direction, pump, valves) Check the circulation (direction, pump, valves) Check the cleanliness of the heat exchanger
L10	DEP-RET>MAX	PCU	Difference between the flow and return temperatures insufficient	 Sensor fault Check the Ohmic value of the sensor Replace the sensor if necessary Bad connection Check that the sensor has been correctly fitted No water circulation Vent the air in the heating system Check the circulation (direction, pump, valves) Check the vater pressure Check the cleanliness of the heat exchanger Check that the heating pump is operating correctly

Code	Faults	Cause	Description	Checking / solution
		of the fault		
L11	RET-DEP>MAX	PCU	Difference between the flow	Sensor fault
			and return temperatures too	 Check the Ohmic value of the sensor
			great	 Replace the sensor if necessary
				Bad connection
				Check that the sensor has been correctly fitted
				No water circulation
				 Vent the air in the heating system
				 Check the circulation (direction, pump, valves)
				 Check the water pressure
				• Check the cleanliness of the heat exchanger
				• Check that the heating pump is operating correctly
L12	STB OPEN	PCU	Maximum boiler temperature	Bad connection
			exceeded (STB thermostat maximum)	 Check the wiring between the PCU PCB and the STB
				• Check that the SU PCB is correctly in place
				 Check the electrical continuity of the STB
				• Check whether the STB has been correctly fitted
				Sensor fault
				 Replace the STB if necessary
				No water circulation
				 Vent the air in the heating system
				 Check the circulation (direction, pump, valves)
				Check the water pressure
				• Check the cleanliness of the heat exchanger
L14	BURNER FAILURE	PCU	5 burner start-up failures	No ignition
				 Check the wiring between the PCU PCB and the ignition transformer
				 Check that the SU PCB is correctly in place
				Check the ionization/ignition electrode
				Check the earthing
				SU PCB faulty: Change the PCB
				Ignition arc, but no flame formation
				 Vent the gas flues
				 Check that the gas valve is fully opened
				 Checking the gas supply pressure
				 Check the operation and setting of the gas valve unit
				 Check that the air inlet and flue gas discharge flues are not blocked
				 Check the wiring on the gas valve unit
				SU PCB faulty: Change the PCB
				Presence of the flame but insufficient ionization (<3 μ A)
				 Check that the gas valve is fully opened
				Checking the gas supply pressure
				Check the ionization/ignition electrode
				Check the earthing
				Check the wiring on the ionization/ignition
				electrode



Code	Faults	Cause of the fault	Description	Checking / solution
L16	PARASIT FLAME	PCU	Detection of a parasite flame	Ionization current present when there should not be a flame Ignition transformer defective
				 Check the ionization/ignition electrode
				Gas valve defective
				 Check the gas valve and replace if necessary
				The burner remains very hot: CO ₂ too high
1.47		5011		Set the CO ₂
L17	VALVE FAIL	PCU	Problem on the SU PCB	Bad connection
				Check that the SU PCB is correctly in place
				SU PCB faulty
				 Inspect the SU PCB and replace it if need be
L34	FAN FAILURE	PCU	The fan is not running at the	Bad connection
			right speed	 Check the wiring between the PCU PCB and the fan
				Fan defective
				 Check for adequate draw on the chimney connection
				 Replace the fan if need be
L35	BACK>BOIL FAIL	PCU	Flow and return reversed	Bad connection
				Check that the sensor has been correctly fitted
				Sensor fault
				 Check the Ohmic value of the sensors
				 Replace the sensor if necessary
				Water circulation direction reversed
				 Check the circulation (direction, pump, valves)
L36	I-CURRENT FAIL	PCU	The flame went out more than	No ionization current
			5 times in 24 hours while the	 Purge the gas supply to remove air
			burner was operating	 Check that the gas valve is fully opened
				 Checking the gas supply pressure
				 Check the operation and setting of the gas valve
				unit
				 Check that the air inlet and flue gas discharge flues
				are not blocked
L37	SU COM.FAIL	PCU	Communication failure with the	Check that there is no recirculation of flue gases Bad connection
			SU PCB	
				 Check whether the SU PCB has been correctly fitted into the connector on the PCU PCB
				 Change the SU PCB
L38	PCU COM.FAIL	PCU	Communication failure	Bad connection
			between the PCU and SCU PCBs	Check the wiring between the PCU and SCU PCBs
				Run an AUTODETECTION in the menu
				#CONFIGURATION
				SCU PCB not connected or faulty
				Replace the SCU PCB

Code	Faults	Cause of the fault	Description	Checking / solution
L39	BL OPEN FAIL	PCU	The BL inlet opened for a short time	 Check the wiring External cause Check the device connected to the BL contact Parameter incorrectly set
L40	TEST.HRU.FAIL	PCU	HRU/URC unit test error	 Check the parameter IN.BL Bad connection Check the wiring Parameter incorrectly set Set the type of generator again in the menu #CONFIGURATION (Refer to the original rating plate)
L250	DEF.WATER MIS.	PCU	The water pressure is too low	Hydraulic circuit incorrectly vented Water leak Measurement error Top up with more water if necessary Reset the boiler
L251	MANOMETRE FAIL	PCU	Pressure gauge fault	 Wiring problem The manometer is defective Sensor pcb defective Check the wiring between the PCU PCB and the pressure gauge Check whether the pressure gauge has been correctly fitted Replace the pressure gauge if need be
D03 D04	OUTL S.B FAIL. OUTL S.C FAIL.	SCU	Circuit B flow sensor fault Circuit C flow sensor fault Remarks: The circuit pump is running. The 3-way valve motor on the circuit is no longer powered and can be adjusted manually.	 Bad connection Check whether the sensor is connected: See chapter: "Deletion of sensors from the memory in the PCB", page 106 Check the link and the connectors Check that the sensor has been correctly fitted Sensor fault Check the Ohmic value of the sensor Replace the sensor if necessary
D05	OUTSI.S.FAIL.	SCU	Outside temperature sensor fault Remarks: The boiler operates on BOILER MAX temperature. The valve setting is no longer ensured but monitoring the maximum temperature of the circuit after the valve is ensured. Valves may be manually operated. Reheating the domestic hot water remains ensured.	 Bad connection Check whether the sensor is connected: See chapter: "Deletion of sensors from the memory in the PCB", page 106 Check the link and the connectors Check that the sensor has been correctly fitted Sensor fault Check the Ohmic value of the sensor Replace the sensor if necessary

Code	Faults	Cause	Description	Checking / solution
Soue	radito	of the	Description	Sheeking / Solution
		fault		
D07	SYST.SENS.FAIL.	SCU	System sensor fault	Bad connection
				 Check whether the sensor is connected: See chapter: "Deletion of sensors from the memory in the PCB", page 106
				 Check the link and the connectors
				Check that the sensor has been correctly fitted
				Sensor fault
				 Check the Ohmic value of the sensor
				 Replace the sensor if necessary
D09	DHW S.FAILURE	SCU	Domestic hot water sensor fault	Bad connection
			Remarks: Heating of domestic hot water is no longer ensured. The load pump operates.	 Check whether the sensor is connected: See chapter: "Deletion of sensors from the memory in the PCB", page 106
			The load temperature of the	 Check the link and the connectors
			dhw tank is the same as the boiler.	 Check that the sensor has been correctly fitted
				Sensor fault
				 Check the Ohmic value of the sensor
				 Replace the sensor if necessary
D11 D12 D13	ROOM S.A FAIL. ROOM S.B FAIL. ROOM S.C FAIL.	OOM S.B FAIL. fa OOM S.C FAIL. B fa	A room temperature sensor fault B room temperature sensor fault C room temperature sensor	 Bad connection Check whether the sensor is connected: See chapter: "Deletion of sensors from the memory in the PCB", page 106
			fault	 Check the link and the connectors
			Note:	• Check that the sensor has been correctly fitted
			The circuit concerned operates without any influence from the	Sensor fault
			room sensor.	Check the Ohmic value of the sensor
				 Replace the sensor if necessary
D14	MC COM.FAIL	SCU	Communication failure	Bad connection
			between the SCU PCB and the boiler radio module	 Check the link and the connectors
				Boiler module failure
				Change the boiler module
D15	ST.TANK S.FAIL	SCU	Storage tank sensor fault	Bad connection
-			Note: The hot water storage tank reheating operation is no longer assured.	 Check whether the sensor is connected: See chapter: "Deletion of sensors from the memory in the PCB", page 106 Check the link and the connectors Check that the sensor has been correctly fitted
				Sensor fault
				 Check the Ohmic value of the sensor
				 Replace the sensor if necessary


Code	Faults	Cause of the	Description	Checking / solution	
		fault			
D16	SWIM.P.B. S.FAIL	SCU	Swimming pool sensor fault	Bad connection	
D16	SWIM.P.C. S.FAIL		circuit B Swimming pool sensor fault circuit C Note:	 Check whether the sensor is connected: See chapter: "Deletion of sensors from the memory in the PCB", page 106 	
			Swimming pool reheating is always done during the circuit's	 Check the link and the connectors 	
			comfort period.	Check that the sensor has been correctly fitted	
				Sensor fault	
				 Check the Ohmic value of the sensor 	
D (7				Replace the sensor if necessary	
D17	DHW 2 S.FAIL	SCU	Sensor fault tank 2	Bad connection	
				 Check whether the sensor is connected: See chapter: "Deletion of sensors from the memory in the PCB", page 106 	
				 Check the link and the connectors 	
				Check that the sensor has been correctly fitted	
				Sensor fault	
				 Check the Ohmic value of the sensor 	
				 Replace the sensor if necessary 	
D27	PCU COM. FAIL	SCU	Communication failure between the SCU and PCU PCBs		
			Check the wiring between	the SCU and PCU PCBs	
			 Check that the PCU PCB is powered up (green LED on or flashing) 		
			Change the PCU PCB		
D32	5 RESET:ON/OFF	SCU	5 resets done in less than an hour		
			Switch the boiler off and switch back on		
D37	TA-S SHORT-CIR	SCU	 The Titan Active System® is sh Check that the connection circuited Check that the anode is not 	cable between the SCU PCB and the anode is not short-	
			Remarks:	a short-circuited	
			Domestic hot water production h 远.	nas stopped but can nonetheless be restarted using key	
				stem® is connected to the boiler,check that the TAS with package AD212) is fitted to the sensor card.	
D38	TA-S DISCONNEC	SCU	The Titan Active System® is on	· · · · · ·	
			 Check that the connection of 	cable between the SCU PCB and the anode is not severed	
			 Check that the anode is no 		
			Remarks:		
				nas stopped but can nonetheless be restarted using key	
			ि. The tank is no longer protected.		
			If a tank without Titan Active Sy	stem® is connected to the boiler,check that the TAS with package AD212) is fitted to the sensor card.	
D99	DEF.BAD PCU	SCU	The SCU software version does not recognise the PCU connected		
			 Update the SCU with the a 	ppropriate software version	

8.4.1. Deletion of sensors from the memory in the PCB

The configuration of the sensors is memorised by the SCU PCB. If a sensor fault appears whilst the corresponding sensor is not connected or has been voluntarily removed, please delete the sensor from the SCU PCB memory.


- Press key ? repeatedly until Do you want to delete this sensor? is displayed.
- Select **YES** by turning the rotary button and press to confirm.
 - The outside temperature sensor cannot be deleted.

8.5 Failure history



.

8.6 Parameter and input/output check (mode tests)



Use the following menus to target the cause of a malfunction.

Access the "After Sales" level: Hold down the
 <u>h</u> key until
 <u></u> key until
 <u></u>

2. Check the following parameters:

- Turn the rotary button to scroll through the menus or modify a value.
- Press the rotary button to access the selected menu or confirm a value modification.

For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 49

After Sales level - Menu #PARAMETERS		
Parameter	Description	
PERMUT	Master boiler active	
STAGE	Number of boilers requesting heating	
NB.CASC.:	Number of boilers recognised in the cascade	
NB. VM:	Number of DIEMATIC VM control systems recognised in the cascade	
POWER %	Current output of the boiler	
PERCENT PUMP	Modulating pump command	
SPEED FAN ⁽¹⁾	Fan rotation speed	
SETPOINT FAN	Fan rotation speed desired	
MEAN OUTSIDE T	Average outside temperature	
CALC.T. BOILER	Temperature calculated by the boiler	
BURNER SETPOINT	Set point parameter of the burner	
AVERAGE BOIL.T	Average temperature of the boiler flow sensor	
BOILER. T. ⁽¹⁾	Measurement of the boiler flow sensor	
BACK TEMP ⁽¹⁾	Temperature of the boiler return water	
SYSTEM TEMP. ⁽¹⁾	Temperature of the system flow water if multi-generator	
SYST. CALC. T. ⁽²⁾	System flow temperature calculated by the control system	
CALCULATED T. A	Calculated temperature for circuit A	
CALCULATED T. B ⁽³⁾	Calculated temperature for circuit B	
CALCULATED T. C ⁽³⁾	Calculated temperature for circuit C	
OUTLET TEMP. B ⁽¹⁾ (3)	Temperature of the flow water in circuit B	
SWIMMING P.T.B	Temperature of the swimming pool water sensor on circuit B	
OUTLET TEMP. C ⁽¹⁾ (3)	Temperature of the flow water in circuit C	
SWIMMING P.T.C	Temperature of the swimming pool water sensor on circuit C	
OUTSIDE TEMP. ⁽¹⁾	Outside temperature	
ROOMTEMP. A ⁽¹⁾	Room temperature of circuit A	
ROOMTEMP. B ⁽¹⁾ ⁽³⁾	Room temperature of circuit B	
ROOMTEMP. C ⁽¹⁾ ⁽³⁾	Room temperature of circuit C	
(2) The parameter is only of	displayed by pressing key ഥ. displayed if CASCADE: is set to ON displayed for the options, circuits or sensors actually connected	

15/06/12 - 300022159-001-01



107

After Sales level - Menu #PARAMETERS Parameter Description WATER TEMP. (1)(3) Water temperature in the DHW tank IN 0-10V (1)(3) Voltage at input 0-10 V CURRENT⁽¹⁾ Ionization current PRESSURE (1) Water pressure in the installation Water temperature in the storage tank STOR.TANK.TEMP (1) (3) T.DHW BOTTOM (1)(3) Water temperature in the bottom of the DHW tank **DHW A TEMP.** ⁽¹⁾⁽³⁾ Water temperature in the second DHW tank connected to circuit A TEMP.TANK AUX (1)(3) Water temperature in the second DHW tank connected to the AUX circuit KNOB A Position of temperature setting button on room sensor A **KNOB B**⁽³⁾ Position of temperature setting button on room sensor B **KNOB** C⁽³⁾ Position of temperature setting button on room sensor C OFFSET ADAP A Parallel trigger calculated for circuit A OFFSET ADAP B (3) Parallel trigger calculated for circuit B OFFSET ADAP C ⁽³⁾ Parallel trigger calculated for circuit C (1) The parameter can be displayed by pressing key PA. (2) The parameter is only displayed if CASCADE: is set to ON

(3) The parameter is only displayed for the options, circuits or sensors actually connected

After Sales level - Menu #TEST OUTPUTS			
Parameter	ameter Adjustment range Description		
P. CIRC. A	ON / NO	Stop/start pump circuit A	
P. CIRC. B ⁽¹⁾	ON / NO	Stop/start pump circuit B	
P. CIRC. C ⁽¹⁾	ON / NO	Stop/start pump circuit C	
HW. PUMP ⁽¹⁾	ON / NO	Stop/start domestic hot water pump	
AUX.CIRC. ⁽¹⁾	ON / NO	On/Off auxiliary outlet	
3WV B ⁽¹⁾ REST No command		No command	
	OPEN	Opening 3-way valve circuit B	
	CLOSE	Closure 3-way valve circuit B	
3WV C ⁽¹⁾	V C ⁽¹⁾ REST No command		
	OPEN	Opening 3-way valve circuit C	
	CLOSE	Closure 3-way valve circuit C	
TEL.OUTPUT	ON / NO	On/Off telephone relay outlet	
(1) The parameter	is only displayed for the or	otions, circuits or sensors actually connected	

Parameter	Status	Description
PHONE REM.		Bridge on telephone input (1 = presence, 0 = absence)
FLAME		Flame presence test (1 = presence, 0 = absence)
GAS VALVE	OPEN/CLOSE	Opening the valve Closing the valve
FAILURE	ON	Fault display
	OFF	No fault



Parameter	Status	Description
SEQUENCE		Control system sequence. See chapter: "Control system sequence", page 110
BOILER		Index of the generator in the system
ТҮРЕ		Generator type
R.CTRL A ⁽¹⁾	ON	Presence of a remote control A
	OFF	No remote control A
R.CTRL B ⁽¹⁾	ON	Presence of a remote control B
	OFF	No remote control B
R.CTRL C ⁽¹⁾	ON	Presence of a remote control C
	OFF	No remote control C
CALIBRA.CLOCK ⁽²⁾		Clock calibration

After Sales level - #INFORMATION menu		
Parameter	Description	
S/N SCU	Serial number of the SCU board	
CTRL	Software version of the SCU board	
S/N PCU	Serial number of the PCU board	
VER.ROM	Version of the PCU PCB programme	
VERS.PARAM PCU	Version of the PCU PCB parameters	
S/N SU	Serial number of the SU board	
VERS.PARAM SU	Version of the SU PCB programme	
VERS.PARAM PCU	Version of the SU PCB parameters	
MC.VERSION ⁽¹⁾	Version of the boiler radio module programme	
SOLAR VERS. ⁽¹⁾	Solar control system software version	
CALIBRA.CLOCK ⁽²⁾	Clock calibration	
 The parameter is only displayed for the options, circuits or sensors actually connected The parameter is only displayed if INSTALLATION is set to EXTENDED 		

After Sales level - Menu #CONFIGURATION			
Parameter	Adjustment range	Description	
MODE:	MONO/ ALL.CIRC.	To chose if the exemption made for one remote control applies to a single circuit (MONO) or if it must be transmitted to a group of circuits (ALL.CIRC.)	
TYPE		Generator type (Refer to the original rating plate)	
AUTODETECTION	OFF/ON	System reset if error L38 is displayed	
TAS	OFF/ON	Activation of the Titan Active System® function	



8.6.1. Control system sequence

Contro	rol system sequence				
Status	Sub-status	Operation			
0	0	Boiler stopped			
1	1	Anti-short cycle activated			
	2	Reversal valve opening			
	3	Start-up of the boiler pump			
	4	Awaiting burner start-up			
2	10	Open gas valve (External)			
	11	Fan start-up			
	13	The fan switches to the burner start-up speed			
	14	Check RL signal (Function not active)			
	15	Burner on switch request			
	17	Pre-ignition			
	18	Ignition			
	19	Check flame presence			
	20	Awaiting further action to unsuccessful ignition			
3/4	30	Burner lit and free modulation on the boiler instruction			
	31	Burner lit and free modulation on a limited instruction, equal to a return temperature of +25°C			
	32	Burner ignited and free modulation on the boiler set point but output restricted			
	33	Burner lit and descending modulation following too large a rise in temperature on the exchanger (4 K in 10 seconds)			
	34	Burner lit and minimum modulation following too large a rise in temperature on the exhanger (7 K in 10 seconds)			
	35	Burner off following too large a rise in temperature on the exchanger (9 K in 10 seconds)			
	36	Burner lit and ascending modulation to guarantee a correct ionization current			
	37	Heating: Burner lit and minimum modulation after a burner start-up lasting 30 seconds			
		DHW production: Burner lit and minimum modulation after a burner start-up lasting 100 seconds			
	38	Burner lit and modulation fixed higher than the minimum after burner start-up lasting 30 seconds, if the burner was off for more than 2 hours or after powering up			
5	40	The burner will stop			
	41	The fan switches to post-sweeping speed on the burner			
	42	The external gas valve closes			
	43	Post-sweeping			
	44	Stop fan			
6	60	Post-operation of the boiler pump			
	61	Stop boiler pump			
	62	Reversal valve closure			
	63	Start anti short cycle			
8	0	Stand-by			
	1	Anti-short cycle activated			
9		Blockage: The sub-status shows the error value			
10		Blocking			
16		Antifreeze protection			
17		Bleed			

9 Spare parts

9.1 General

When it is observed subsequent to inspection or maintenance work that a component in the appliance needs to be replaced, use only original spare parts or recommended spare parts and equipment.



To order a spare part, give the reference number shown on the list.


9.2 Spare parts

Spare parts list reference: 300022159-002-A









EV 119526-1


112

T001498-B



9.2.2. Heat exchanger and burner






EV 119526-2

T001499-B

9.2.3. Fan








EV 119526-3

T001653-B

9.2.4. Control panel








EV 119526-4

T001654-C

9.2.5. Connecting pipes



EV 119526-5

T001655-C

9.2.6. Spare parts list

Markers	Code no.	Description	Part
Casing			
1001	S101309	Front casing	1
1002	S101297	Top cover (Control panel)	1
1006	S101403	Screw	2
Heat exc	hanger and	l burner	L
2001	S100893	Heat exchanger 28kW	1
2002	S100894	Condensate tank 253 mm	1
2003	S100703	Pump Grundfos UPM 15-70 RES	1
2004	S100905	Siphon	1
2005	S100909	Flow and return pipes	1
2006	S100854	Flue gas discharge pipe (28 kW)	1
2007	S100906	Siphon gasket	1
2009	S100815	76x4 O-ring	5
2010	S59597	18x2,8 O-ring	10
2011	S101003	NTC temperature sensor	2
2012	S100890	Ignition/ionization electrode	1
2013	S59118	Sight glass	1
2014	S62105	Sealing plate for the ignition electrode	10
2015	S48950	Screw M4x10	50
2016	S100880	Gasket for burner (28 kW)	1
2017	S62728	Automatic air vent	1
2018	S100895	Endpiece M7x1	1
2019	S100891	Silicone hose 8x4x715	
2020	S100888	Gasket between heat exchanger and condensate collector 219 mm	1
2021	S100892	Gasket between flue gas discharge and condensate collector	1
2022	S100855	Leak proofing ring Ø 80 mm	5
2023	S100850	Protective plug for the combustion gas evacuation measurement point	1
2024	S100901	Holding strip for the heat exchanger	1
2025	S100848	Holding clip for the flue gas discharge pipe	2
2026	S62768	Combustion air/flue gas adapter 60/100	1
2028	S62232	Protective plug for the combustion gas evacuation measurement point	5
2029	S62233	Protective plug for the combustion gas evacuation measurement point	5
2030	S59141	Screw M5x18	15
2032	S59586	Hairpin clip 18 mm	10
2033	S100838	Ignition transformer with ignition electrode	1
2034	S100954	Hose clamp	10
2036	S100925	Expansion vessel	1
2037	S100908	Pipe between the pump and the expansion vessel	1
2038	S44483	M8 nut	10
2039	S101007	Serrated washer 8,2	4
2050	S101005	HI temperature sensor	1
Fan			
3001	S101507	Gas block	1
3002	S100878	Fan RG118 - R19,5x1	1
3003	S100879	Burner 198 mm - 28 kW	1
3004	S100881	Leakproof seal Ø 83 mm with valve (28kW)	1
3005	S100882	Gas/air mixer 220x84 mm	1



Markers	Code no.	Description	Part
3006	S101290	Gas inlet pipe	1
3007	S100911	Air intake silencer	1
3008	S56155	Sealing ring Ø 23,8x17,7x2 mm	20
3011	S100951	Screw M5x25	10
3012	S101010	G3/4" nut	1
0	S101542	Propane diaphragm - 4.00 mm	1
Control p	banel		
4001	S101478	PCU-03 PCB	1
4002	S100849	SU-01 PCB	1
4003	S101249	display board	1
4004	S43561	2,00 glass fuse A slow	10
4004	S6778	6,30 glass fuse A slow	10
4006	S100821	Pressure sensor	1
4007	S100838	Ignition transformer with ignition electrode	1
4008	S101003	NTC temperature sensor	2
4009	S100845	Electric cable 1500 mm	1
4009	S101299	24V. sensor cable	1
4009	S101302	Pump cable	1
4009	S101303	Pump cable (DHW)	1
4009	S101305	Gas valve unit and ignition transformer cable	1
4009	S101306	3-way valve cable	1
4010	S59372	Draught diverter	1
4011	S100861	Oval sealing gasket	5
4012	S62185	Screw Kb30x8	10
4014	S101251	Control panel	1
4015	S48950	Screw M4x10	50
4016	S101005	HI temperature sensor	1
4017	S100869	Gasket SCU	1
4018	S100862	SCU grommet	5
4019	S62185	Screw Kb30x8	10
4021	S101048	SCU 04	1
4022	S100860	Box SCU	1
4023	S100843	SCU 230V. cable	1
4024	S100847	SCU cable	1
4030	S101000	grommet	5
Connect	ing pipes		
5001	S100831	Plate heat exchanger	1
5002	S100823	Actuator with 3-way valve	1
5004	S100822	Right hand hydroblock + actuator + pressure sensor	1
5006	S100828	Left hand hydroblock	1
5007	S100824	Cartridge body	1
5008	S100829	Safety valve with hose	1
5010	S100821	Pressure sensor	1
5011	S100815	76x4 O-ring	5
5012	S59597	18x2,8 O-ring	10
5013	S59586	Hairpin clip 18 mm	10
5014	S100873	Hose holding clip	5
5015	S100835	Hairpin clip 16 mm	10
5016	S100810	25,2x17 O-ring	20
5017	S100813	Clip 26	20
5018	S100816	22x2,5 O-ring	10



Markers	Code no.	Description	Part
5019	S100826	Screw K50x28	10
5020	S100836	Screw M5x15	10
5023	S100832	Clip 26 with handle	20
5025	S59141	Screw M5x18	15
5027	S101002	Condensate evacuation hose	1
5029	S100825	Screw K50x12	20
5030	S62727	Grommet Ø 20 mm	15
5037	S101046	Holding clip	1
5038	S100875	Valve G3/4" disconnector	1
5039	S100871	Valve 1/2" DHW end	1
5040	S100874	Valve G1/2" disconnector	1
5041	S100872	Gas valve	1
5042	S100876	Pressure gauge	1
5043	S100231	M10x1x5 nut	10
5044	S101193	Disconnector	1
5045	S101011	Set of pipes (disconnector)	1
5046	S101294	Mounting frame	1
5047	S100246	Set of pipes with filling and safety valve	1
5048	S101195	Union nut 3/8"x12	2
5049	S62715	Seal ø 14.5x8.5x2	10
5050	S100238	Condensates collector	1
5051	S100912	Set of pipes 16/18/22 mm	1
5052	S56157	Seal ø 18.3x12.7x2	10
5053	S56155	Seal ø 23.8x17.7x2	20
5055	S100805	Filter Central heating	1
5056	S100241	PVC 12/9 hose650 mm	1
5057	S100896	Pipe for pressure gauge	1
5058	S101293	Expansion vessel bracket	1
5059	S101292	Domestic expansion vessel hose	1
5060	S101313	Set of pipes	1
5061	S101288	Bracket	1
5062	S101324	NTC sensor	1
5063	S101291	DHW expansion vessel	1
5064	S101314	Piping kit	1
5065	S56156	Seal ø 30x21x3	10
5066	S101316	Pump Upo 15-30	1
5067	S101317	Connection fitting	1
5069	S101318	Hydroblock	1
5070	S101320	Calorifier tank with insulation and sensor	1
5071	S101322	Insulation	1
5072	S101310	Spring	1
5073	S101311	DHW sensor	1
5077	S101323	Union nut G1"	1

9. Spare parts

DE DIETRICH	()			
ER 57, ru F- 67580 Ø +33 (0	www.dedietrich-thermique.fr Direction des Ventes France 57, rue de la Gare F- 67580 MERTZWILLER Ø Ø +33 (0)3 88 80 27 00 € +33 (0)3 88 80 27 99			
DE DIETRICH REMEHA GmbH www.dedietrich-remeha.de Rheiner Strasse 151 D- 48282 EMSDETTEN 12000 + 49 (0)25 72 / 23-5 149 (0)25 72 / 23-102 info@dedietrich.de	NEUBERG S.A. www.dedietrich-heating.com 39 rue Jacques Stas L- 2010 LUXEMBOURG Ø +352 (0)2 401 401			
VAN MARCKE www.vanmarcke.be Weggevoerdenlaan 5 B- 8500 KORTRIJK ¢ +32 (0)56/23 75 11	DE DIETRICH www.dedietrich-otoplenie.ru 129164, Россия, г. Москва Зубарев переулок, д. 15/1 Бизнес-центр «Чайка Плаза», офис 309 ♀ +7 (495) 221-31-51 dedietrich@nnt.ru			
DE DIETRICH www.dedietrich-heating.com Room 512, Tower A, Kelun Building 12A Guanghua Rd, Chaoyang District C-100020 BEIJING € +86 (0)106.581.4017 +86 (0)106.581.4018 +86 (0)106.581.7056 € +86 (0)106.581.4019 contactBJ@dedietrich.com.cn	ÖAG AG www.oeag.at Schemmerlstrasse 66-70 A-1110 WIEN ♀ +43 (0)50406 - 61624 ↔ +43 (0)50406 - 61569 dedietrich@oeag.at			
WALTER MEIER (Klima Schweiz) AG www.waltermeier.com Bahnstrasse 24 CH-8603 SCHWERZENBACH +41 (0) 44 806 44 24 Serviceline +41 (0)8 00 846 846 ← +41 (0) 44 806 44 25 ch.klima@waltermeier.com	WALTER MEIER (Climat Suisse) SA www.waltermeier.com Z.I. de la Veyre B, St-Légier CH-1800 VEVEY 1 𝔅 +41 (0) 21 943 02 22 Serviceline +41 (0)8 00 846 846 𝑘 +41 (0) 21 943 02 33 ch.climat@waltermeier.com			
DUEDI S.r.I.www.duediclima.itDistributore Ufficiale Esclusivo De Dietrich-Thermique ItaliaVia Passatore, 12 - 12010 San Defendente di Cervasca CUNEO∅+39 0171 857170 ★ +39 0171 687875 info@duediclima.it	DE DIETRICH THERMIQUE Iberia S.L.U. www.dedietrich-calefaccion.es Av. Princep d'Astúries 43-45 08012 BARCELONA ☞ +34 932 920 520 ☞ +34 932 184 709			
as well as any drawings and technical de and shall not be multiplied without our pr	on contained in these technical instructions, escriptions supplied, remain our property rior consent in writing.			
15/06/12		Viotrich \land		



