


1 8532 0X



Order number	Outlets	L	Distributor cabinet *)
1 8532 03	3	221	1 8569 03
1 8532 04	4	271	
1 8532 05	5	321	1 8569 04
1 8532 06	6	371	1 8569 05
1 8532 07	7	421	1 8569 10
1 8532 08	8	471	
1 8532 09	9	521	1 8569 15
1 8532 10	10	571	
1 8532 11	11	621	
1 8532 12	12	671	1 8569 20
1 8532 13	13	721	
1 8532 14	14	771	
1 8532 15	15	821	1 8569 25
1 8532 16	16	871	

*) Minimum size for distributor cabinet. By using shut-off valves the size of distributor cabinet has to be dimensioned larger.

Spare parts

- 3 F900 01 Flowmeter 0 – 2,5 l/min
- 1 6819 32 Presetting key for Flowmeter
- 1 6403 31 Thermostatic upper part
- 1 6413 01 Shut- off upper part